

DECAP ROD ASSEMBLIES - REDDING DECAP ROD ASSEMBLY

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Includes decapping pin and expander ball Replacement decap rod assembly for Redding sizing dies.



Attributes

- Name: [REDDING DECAP ROD ASSEMBLY](#)
- Manufacturer: [REDDING](#)
- Product no.: 749002388
- Mfr. No.: 31203
- Cartridge: 20 Tactical, 204 Ruger
- Delivery weight: 0.041kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 611760312038

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY
- About Us

Safety Instruction Guide for DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY

Introduction

Thank you for choosing the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. This product is designed for use with Redding sizing dies and includes a decapping pin and expander ball. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always inspect the product for damage before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Follow all manufacturer instructions and guidelines for use and maintenance.
- In case of an incident or injury, report it to the relevant authorities.

Specific Safety Precautions for Use

- Use appropriate eye protection when handling or operating the decap rod assembly.
- Do not exceed the recommended cartridge specifications (e.g., 204 Ruger, 20 Tactical) when using this product.
- Avoid wearing loose clothing or jewelry that may get caught in moving parts.
- Ensure that your workspace is clean and free of clutter to prevent accidents.
- Always work in a wellventilated area to avoid inhalation of any fumes or particles.

Instructions for Installation and Usage

1. Installation

- Ensure the sizing die is securely mounted in your reloading press.
- Remove the old decap rod assembly if necessary.
- Insert the new decap rod assembly into the sizing die, ensuring it fits snugly.
- Tighten any necessary screws or fasteners to secure the assembly in place.

2. Usage

- Before reloading, ensure that the reloading press is in a stable position.
- Place the cartridge case in the shell holder and engage the press to begin the decapping process.
- Monitor the decapping pin for any signs of wear or damage during use.
- If resistance is felt during operation, stop immediately and check for obstructions.

Disposal Instructions

- Dispose of the product according to local regulations.
- Do not dispose of in regular household waste if the product is damaged or contains hazardous materials.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any questions, concerns, or safety inquiries regarding the DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY, please consult the manufacturer's website or customer service resources.

By following these guidelines, you can ensure a safe and effective experience with your DECAP ROD ASSEMBLIES REDDING DECAP ROD ASSEMBLY. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk