

CASE TRIMMER POWER ADAPTER - SINCLAIR INTERNATIONAL CASE TRIMMER POWER ADAPTER

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Trimmer Accessories](#)

The Sinclair L.E. Wilson power adapter for the standard Wilson trimmer cutter replaces the L.E. Wilson crank handle and allows you to use a power screwdriver or drill to power your case trimming. Will work for all models of Sinclair and L.E. Wilson case trimmers, including 50BMG.

Power Adapter for Std & Carbide Wilson Trimmer Cutter



Attributes

- Name: [SINCLAIR INTERNATIONAL CASE TRIMMER POWER ADAPTER](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749002495
- Mfr. No.: WSA
- Caliber: Universal
- Delivery weight: 0.032kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for CASE TRIMMER POWER ADAPTER
- About Us

Safety Instruction Guide for CASE TRIMMER POWER ADAPTER

Introduction

Thank you for choosing the CASE TRIMMER POWER ADAPTER by Sinclair International. This guide provides important safety instructions and information to ensure the safe and effective use of your product. Please read this guide carefully before using the power adapter.

General Safety Guidelines

- Ensure that the power adapter is only used with compatible trimmer models as specified by the manufacturer.
- Always check the power adapter for any signs of damage before use. If damaged, do not use the adapter and contact the manufacturer for assistance.
- Keep the power adapter out of reach of children and pets to prevent accidents.
- Avoid using the power adapter in wet or damp environments to prevent electrical hazards.
- Do not attempt to repair or modify the power adapter. Any unauthorized modifications may pose safety risks.

Specific Safety Precautions for Use

- Only use the power adapter in accordance with the manufacturer's instructions.
- Do not overload the power adapter by connecting it to multiple devices at once.
- Ensure that the power outlet is properly grounded and capable of handling the power requirements of the adapter.
- Disconnect the power adapter from the electrical outlet when not in use or before cleaning.
- If the power adapter overheats, disconnect it immediately and allow it to cool down before using it again.

Instructions for Installation and Usage

1. Installation:

- Locate a suitable power outlet that meets the voltage requirements of the power adapter.
- Plug the power adapter into the power outlet securely.
- Connect the power adapter to the trimmer cutter, ensuring a firm connection.

2. Usage:

- Turn on the power adapter and ensure that the trimmer cutter is functioning correctly.
- Monitor the operation of the trimmer while it is connected to the power adapter.
- If you notice any unusual sounds or smells, disconnect the power adapter immediately and inspect it for issues.

3. Maintenance:

- Regularly inspect the power adapter for any signs of wear or damage.
- Keep the power adapter clean and free from dust and debris.
- Store the power adapter in a cool, dry place when not in use.

Disposal Instructions

- Dispose of the power adapter in accordance with local regulations regarding electronic waste.
- Do not dispose of the power adapter in regular household waste.
- Consider recycling the power adapter to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or concerns regarding the CASE TRIMMER POWER ADAPTER, please reach out to the manufacturer or consult the product documentation for authorized contact points.

Please remember to adhere to these safety guidelines to ensure a safe and effective experience with your CASE TRIMMER POWER ADAPTER. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk