

# SMALL BRICK BAG - PROTEKTOR SMALL BRICK BAG

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Small size brick shaped bag. Popular for use under your elbow. Bag size is four inches wide by five inches long by one and a half inches high. Note: Sand is required to fill this bag.



## Attributes

- Name: [PROTEKTOR SMALL BRICK BAG](#)
- Manufacturer: [PROTEKTOR](#)
- Product no.: 749002542
- Mfr. No.: 17
- Color: Tan
- Material: Leather
- Style: Brick
- Delivery weight: 0.113kg

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for SMALL BRICK BAG PROTEKTOR](#)
- [About Us](#)

# Safety Instruction Guide for SMALL BRICK BAG PROTEKTOR

## Introduction

Thank you for choosing the SMALL BRICK BAG PROTEKTOR. This guide provides important safety instructions and guidelines to ensure the safe and effective use of your new brickshaped bag. Please read this document carefully before using the product.

## General Safety Guidelines

- Always ensure that the bag is filled with sand as required for proper use.
- Keep the bag out of reach of children to prevent accidental injury.
- Inspect the bag regularly for any signs of wear or damage before each use.
- Do not use the bag for purposes other than those intended, such as lifting heavy objects.
- If you notice any defects or issues, discontinue use immediately and report the problem.

## Specific Safety Precautions for Use

- **Filling the Bag:** Use only clean, dry sand to fill the bag. Ensure the bag is securely closed after filling to prevent spillage.
- **Using the Bag:** Place the bag on a stable surface. Do not place your body weight on the bag while it is not filled, as it may cause instability.
- **Handling:** Always lift the bag with both hands to avoid strain. Avoid dragging the bag across rough surfaces to prevent damage.

## Instructions for Installation and Usage

### 1. Filling the Bag:

- Open the zipper or closure of the bag.
- Fill the bag with sand until it reaches the desired weight.
- Close the bag securely to prevent sand from leaking out.

### 2. Using the Bag:

- Position the bag under your elbow or as intended during use.
- Ensure that the bag is stable and will not slip during use.
- If using for shooting or resting purposes, ensure that the surface is level and secure.

### 3. Cleaning and Maintenance:

- Wipe the exterior of the bag with a damp cloth to clean.
- Do not use harsh chemicals or abrasive materials on the bag.
- Store the bag in a dry place when not in use.

## Disposal Instructions

- When the bag reaches the end of its useful life, dispose of it in accordance with local regulations.
- If the bag is damaged or cannot be filled, do not attempt to repair it. Dispose of it responsibly.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the SMALL BRICK BAG PROTEKTOR, please refer to the contact information provided by the manufacturer or retailer.

## **Conclusion**

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your SMALL BRICK BAG PROTEKTOR. Always prioritize safety and report any concerns to the appropriate authorities. Thank you for your attention to these important safety measures.

# About Us

## Brownells Europe

**Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

P.O.Box 4300  
Warwick  
CV34 9BR

[www.brownells.eu](http://www.brownells.eu)