

SINCLAIR REST POST- STAINLESS STEEL - SINCLAIR INTERNATIONAL SHOOTING REST POST, 4", STAINLESS STEEL

[Shooting Accessories](#) > [Shooting Rests](#) > [Shooting Rest Accessories](#)

Every new Sinclair Rest comes with a post, but if you are planning to use more than one top on your rest, order a post for each additional top. Our rest post is stainless steel and precision machined threads and a one fourth - twenty hole for the top mounting screw. These posts are machined specifically for Sinclair Rifle Rest, but will usually fit Hart handwheels also. Only fits the lite weight rest and Gen I Varmint, Does not fit Gen II Rest. Post is 4 inches long, undersized to three fourths - ten thread.



Attributes

- Name: [SINCLAIR INTERNATIONAL SHOOTING REST POST, 4", STAINLESS STEEL](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749002618
- Mfr. No.: 042503
- Style: Rest Accessories
- Delivery weight: 0.249kg
- Shipping height: 20mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- Sinclair Rest Post Safety Instruction Guide
- About Us

Sinclair Rest Post Safety Instruction Guide

Introduction

Thank you for choosing the Sinclair Rest Post. This guide provides essential safety instructions and information to ensure the safe and effective use of your product. Please read this guide carefully before using the Sinclair Rest Post.

General Safety Guidelines

- Ensure that the Sinclair Rest Post is used only for its intended purpose as specified in this manual.
- Always inspect the product before use for any signs of damage or wear.
- Keep the Sinclair Rest Post out of reach of children and vulnerable individuals.
- If you notice any defects or irregularities, discontinue use immediately and seek assistance.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use the Sinclair Rest Post only with compatible Sinclair Rifle Rest models.
- Do not attempt to modify the rest post or use it in a manner that is not recommended by the manufacturer.
- Ensure that all connections are secure before using the rest post.
- Avoid using the rest post in wet or damp conditions to prevent slipping or stability issues.
- Be cautious when handling the stainless steel post to avoid cuts or injuries.

Instructions for Installation and Usage

1. Installation

- Ensure you have the following tools ready:
 - Compatible Sinclair Rifle Rest
 - One fourth twenty mounting screw
- Align the Sinclair Rest Post with the mounting hole of the rest.
- Insert the one fourth twenty mounting screw through the post and into the mounting hole.
- Tighten the screw securely without overtightening to avoid damage.

2. Usage

- Place the Sinclair Rifle Rest on a stable, flat surface.
- Adjust the height of the rest post as needed for your shooting position.
- Ensure that the rest is stable before proceeding with any shooting activities.
- After use, detach the rest post if not needed for future sessions.

Disposal Instructions

- Dispose of the Sinclair Rest Post in accordance with local regulations for metal waste.
- Do not dispose of the product in general household waste.
- If the rest post is damaged beyond repair, ensure that it is recycled or disposed of properly to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the Sinclair Rest Post, or to report unsafe products, please contact the

appropriate authority in your region. Ensure to keep this manual for future reference.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Sinclair Rest Post!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk