

L.E. WILSON TRIMMER ACCESSORIES - SHARKFIN CLAMP ATTACHMENT

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Trimmer Accessories](#)

The Sinclair Shark Fin Trimmer Clamp is a quicker, easier way to hold the case holder down on Wilson Trimmers. This clamp will fit any trimmer mounted on a Sinclair Trimmer Stand.



Attributes

- Name: [SHARKFIN CLAMP ATTACHMENT](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749003060
- Mfr. No.:
- Delivery weight: 0.045kg
- Shipping height: 1mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [L.E. WILSON TRIMMER ACCESSORIES SHARKFIN CLAMP ATTACHMENT Safety Instructions](#)
- [About Us](#)

L.E. WILSON TRIMMER ACCESSORIES SHARKFIN CLAMP ATTACHMENT Safety Instructions

Introduction

Thank you for choosing the L.E. Wilson Trimmer Accessories Sharkfin Clamp Attachment. This product is designed to provide a secure and efficient way to hold the case holder down on Wilson Trimmers. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

To ensure your safety and the safety of others while using the Sharkfin Clamp Attachment, please follow these general safety guidelines:

- Always read and understand the product manual before use.
- Ensure the product is suitable for the trimmer model you are using.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the clamp for any signs of damage or wear before each use.
- Do not use the clamp for any purpose other than its intended use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

When using the Sharkfin Clamp Attachment, please adhere to the following safety precautions:

- Ensure that the trimmer is turned off and unplugged before attaching or adjusting the clamp.
- Do not exceed the recommended weight limit for the clamp.
- Avoid placing fingers or hands near moving parts of the trimmer when the clamp is in use.
- Use the clamp only on stable surfaces to prevent tipping or accidents.
- If you experience any discomfort or unusual noise during operation, stop using the product immediately and inspect it for issues.

Instructions for Installation and Usage

Follow these instructions carefully for the correct installation and usage of the Sharkfin Clamp Attachment:

1. Installation:

- Ensure the trimmer is off and unplugged.
- Place the Sharkfin Clamp Attachment onto the designated area of the trimmer.
- Secure the clamp by tightening it according to the manufacturer's specifications.
- Doublecheck that the clamp is firmly attached before proceeding.

2. Usage:

- Once installed, turn on the trimmer.
- Position the case holder securely in the clamp.
- Monitor the operation of the trimmer and the clamp throughout use.
- If adjustments are needed, turn off and unplug the trimmer before making any changes.

3. PostUse:

- After use, turn off and unplug the trimmer.
- Carefully remove the Sharkfin Clamp Attachment.

- Store the clamp in a dry, safe location away from children.

Disposal Instructions

When it comes time to dispose of the Sharkfin Clamp Attachment, please follow these instructions:

- Do not dispose of the product in regular household waste.
- Check local regulations for proper disposal methods for electronic accessories.
- If applicable, recycle the product at designated recycling centers.

Contact Information for Further Support

For any questions or concerns regarding the Sharkfin Clamp Attachment, please refer to the manufacturer's contact information included with your product packaging or visit the manufacturer's website for further assistance.

Thank you for your attention to these safety instructions. Enjoy using your L.E. Wilson Trimmer Accessories Sharkfin Clamp Attachment safely and effectively!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at