

GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS - SIERRA BULLETS 375 CALIBER (0.375") 300GR SPITZER BOAT TAIL 50/BOX

[Reloading](#) > [Bullets](#) > [Rifle Bullets](#)

GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS



Attributes

- Name: [SIERRA BULLETS 375 CALIBER \(0.375"\) 300GR SPITZER BOAT TAIL 50/BOX](#)
- Manufacturer: [SIERRA BULLETS](#)
- Product no.: 749004418
- Mfr. No.: 3000
- Ballistic Coefficient (G1): 0.475
- Brand Style: GameKing
- Bullet Style: Spitzer Boat Tail (SBT)
- Caliber: 375 Caliber
- Diameter (Breech): 0.375
- Diameter (in): 0.375
- Grain: 300
- Sectional Density: 0.305
- Quantity: 50
- Delivery weight: 0.998kg
- UPC: 092763030004

Item details

Made in USA

US export classification: 0A505.x

Table of Contents

- Startpage
- GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS SAFETY INSTRUCTION GUIDE
- About Us

GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS manufactured by SIERRA BULLETS. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before using the bullets to understand the potential hazards and necessary precautions.

General Safety Guidelines

- Always handle ammunition with care and respect.
- Store ammunition in a cool, dry place away from direct sunlight and moisture.
- Keep ammunition out of reach of children and unauthorized users.
- Ensure that you are using the correct caliber and type of bullet for your firearm.
- Familiarize yourself with the operation and safety features of your firearm before use.
- Always wear appropriate eye and ear protection when shooting.
- Follow all local laws and regulations regarding the use of firearms and ammunition.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before inserting or removing bullets.
- Do not use damaged or deformed bullets.
- Avoid exposing ammunition to extreme temperatures or humidity.
- Never point a firearm at anything you do not intend to shoot.
- Always be aware of your surroundings and ensure a safe shooting environment.
- Use only recommended reloading data if you are reloading your own ammunition.
- Never mix different types or brands of ammunition.

Instructions for Installation and Usage

1. Loading the Bullets:

- Ensure that the firearm is pointed in a safe direction.
- Open the action of the firearm and verify that it is unloaded.
- Insert the GAMEKING 375 CALIBER bullets into the magazine or chamber as per the manufacturer's instructions for your specific firearm.

2. Shooting:

- Position yourself in a stable shooting stance.
- Align your sights with the target and ensure the area is clear.
- Firmly grip the firearm and pull the trigger smoothly to fire.

3. PostShooting:

- Once finished shooting, ensure the firearm is unloaded.
- Store any remaining bullets in a secure location.

Disposal Instructions

- Dispose of any unused or damaged bullets in accordance with local regulations.
- Do not throw bullets in regular trash; contact local waste management for proper disposal methods.
- Ensure that any spent cartridges are disposed of safely to prevent injury.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's contact details provided at the time of purchase.

By following these guidelines and instructions, you can ensure a safer experience while using the GAMEKING 375 CALIBER (0.375") SPITZER BOAT TAIL BULLETS. Thank you for your attention to safety, and enjoy your shooting experience responsibly.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu