

204 RUGER BRASS CASE - 204 RUGER BRASS 50/BOX

[Reloading](#) > [Brass](#) > [Rifle Brass](#)

Nosler takes a few extra steps with their brass to make it a premium component for the handloader. The brass is first weigh-sorted to within + or - 0.5 grains, then the flash holes are deburred. Nosler completes the case prep with neck sizing and chamfering the inside and outside of the case mouth. All Nosler unprimed brass bears the Nosler headstamp.



Attributes

- Name: [204 RUGER BRASS 50/BOX](#)
- Manufacturer: [NOSLER](#)
- Product no.: 749005166
- Mfr. No.: 10056
- Cartridge: 204 Ruger
- Rounds: 50
- Quantity: 50
- Delivery weight: 0.635kg
- Shipping height: 86mm
- Shipping width: 117mm
- Shipping length: 117mm
- UPC: 054041100564

Item details

US export classification: 0A505.x

Table of Contents

- Startpage
- Safety Instruction Guide for 204 RUGER BRASS CASE
- About Us

Safety Instruction Guide for 204 RUGER BRASS CASE

Introduction

Thank you for choosing the 204 RUGER BRASS CASE by Nosler. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before use.

General Safety Guidelines

- Always treat all brass cases as if they are loaded.
- Keep ammunition and brass out of reach of children and unauthorized users.
- Inspect brass cases for any signs of damage or defects before use.
- Do not use brass that shows signs of excessive wear or deformation.
- Follow all local laws and regulations regarding the use and storage of ammunition components.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure you are using the correct caliber (204 Ruger) for your firearm.
- Always wear appropriate eye and ear protection when handling ammunition.
- Handle brass cases with clean hands to avoid contamination.
- Store brass in a cool, dry place away from direct sunlight and moisture.
- Avoid using brass that has been submerged in water or exposed to extreme temperatures.
- If you experience a misfire or hangfire, follow proper safety protocols to avoid injury.

Instructions for Installation and Usage

1. **Preparation:** Before use, ensure that your workspace is clean and free of distractions.
2. **Inspection:** Check each brass case for any defects such as cracks or dents.
3. **Loading:**
 - Use a reliable reloading manual to follow recommended loads for the 204 Ruger.
 - Carefully seat primers and check for proper seating depth.
4. **Firing:**
 - Load your firearm according to the manufacturer's instructions.
 - Always point the firearm in a safe direction when loading and unloading.
5. **PostUse:** After firing, inspect brass cases for signs of excessive pressure or damage.

Disposal Instructions

- Dispose of used brass cases in accordance with local regulations.
- Recycle brass cases where possible to minimize environmental impact.
- Do not dispose of brass in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the 204 RUGER BRASS CASE, please refer to the manufacturer's contact details provided on the packaging or visit their website for more information.

Thank you for following these safety instructions. Your adherence to these guidelines helps ensure a safe and enjoyable experience with your 204 RUGER BRASS CASE.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at