

TRIM PRO 3-WAY CUTTERS - RCBS 7MM 3-WAY CUTTER

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Replacement Cutters](#)

The RCBS 3-Way Cutter is designed for use on Trim Pro Case Trimmers and reduces the trimming /deburring chore. The 3-Way Cutter not only trims cases to lengths but an inside blade chamfers the case while an outside blade deburrs it. Install on all Trim Pro Case Trimmers. Order one 3-Way Cutter by caliber and then simply order additional chamfer/pilots for other calibers.



Attributes

- Name: [RCBS 7MM 3-WAY CUTTER](#)
- Manufacturer: [RCBS](#)
- Product no.: 749006008
- Mfr. No.: 90283
- Caliber: 284/7 mm (.284)
- Delivery weight: 0.091kg
- Shipping height: 48mm
- Shipping width: 58mm
- Shipping length: 97mm
- UPC: 076683902832

Item details

Made in USA

Table of Contents

- Startpage
- RCBS TRIM PRO 3WAY CUTTERS Safety Instruction Guide
- About Us

RCBS TRIM PRO 3WAY CUTTERS Safety Instruction Guide

Introduction

Thank you for choosing the RCBS 3Way Cutter for your Trim Pro Case Trimmer. This guide provides important safety instructions to ensure safe and effective use of the product. Please read this guide thoroughly before using the cutter.

General Safety Guidelines

- Always use the cutter in accordance with the manufacturer's instructions.
- Ensure that the cutter is compatible with your Trim Pro Case Trimmer model.
- Regularly inspect the cutter for any signs of damage or wear. Do not use a damaged cutter.
- Keep the cutter out of the reach of children and vulnerable individuals.
- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves during operation.
- Be aware of your surroundings while using the cutter to avoid accidents.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Sharp blades can cause cuts or injuries. Handle with care.
- Improper installation may result in malfunction or injury.

- **Avoiding Hazards:**

- Always ensure the cutter is securely attached to the trimmer before use.
- Keep hands away from the cutting area during operation.
- Do not attempt to modify or repair the cutter yourself. Seek professional assistance if needed.

- **Age Specific Warnings:**

- This product is not intended for use by children. Ensure adult supervision when used in the presence of minors.

Instructions for Installation and Usage

- **Installation:**

1. Ensure the Trim Pro Case Trimmer is unplugged and not in operation.
2. Remove any existing cutter from the trimmer.
3. Align the RCBS 3Way Cutter with the mounting point on the trimmer.
4. Securely attach the cutter according to the manufacturer's instructions.
5. Check that the cutter is firmly in place before proceeding to use.

- **Usage:**

1. Plug in the Trim Pro Case Trimmer and ensure it is functioning properly.
2. Insert the case to be trimmed into the trimmer.
3. Activate the trimmer and allow the cutter to perform the trimming, chamfering, and deburring tasks.
4. Once completed, turn off the trimmer and unplug it before removing the case.

5. Inspect the trimmed case for any sharp edges or burrs before handling.

Disposal Instructions

- Dispose of the cutter and any damaged parts in accordance with local regulations.
- Do not dispose of the cutter in regular household waste. Check for designated disposal or recycling programs for sharp objects.
- Ensure that the cutter is rendered unusable before disposal to prevent accidental injuries.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's website or customer service resources. Ensure that you have your product details on hand for efficient support.

Thank you for prioritizing safety while using the RCBS 3Way Cutter. Your cooperation helps ensure a safe and effective trimming experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk