

SEATER DIES - REDDING SEATER DIE 17 MACH IV

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

The Redding Seating Die includes bullet guide, built-in crimp ring and the proper seating plug. All dies are made using the finest alloy steels obtainable and machined on Hardinge Super-Precision lathes capable of holding the tightest tolerances in the industry. Heat treated in atmospherically controlled furnaces and hand polished for smooth, flawless functioning, these dies will maintain tolerances and last a lifetime. Inspected and ultrasonically cleaned before packaging.



Attributes

- Name: [REDDING SEATER DIE 17 MACH IV](#)
- Manufacturer: [REDDING](#)
- Product no.: 749006246
- Mfr. No.: 92504
- Cartridge: 17 Mach IV
- Die Style: Bullet Seating Dies
- Delivery weight: 0.295kg
- Shipping height: 41mm
- Shipping width: 58mm
- Shipping length: 132mm
- UPC: 611760925047

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Redding Seating Die 17 Mach IV](#)
- [About Us](#)

Safety Instruction Guide for Redding Seating Die 17 Mach IV

Introduction

Thank you for choosing the Redding Seating Die 17 Mach IV. This product is designed for precision bullet seating while ensuring safety during use. This guide provides essential safety instructions and guidelines to help you use this product safely and effectively.

General Safety Guidelines

- Ensure the die is used only for its intended purpose as described in this guide.
- Always wear appropriate safety gear, including safety glasses, when using the die.
- Keep the work area clean and welllit to avoid accidents.
- Store the die in a secure location, out of reach of children and pets.
- Regularly inspect the die for any signs of wear or damage before use.
- Do not attempt to modify or disassemble the die.

Specific Safety Precautions for Use

- Use only compatible cartridges (17 Mach IV) with this die to prevent malfunction.
- Ensure the die is securely mounted in the reloading press before use.
- Avoid overtightening the die to prevent damage.
- Do not exceed recommended load limits as specified in your reloading manual.
- Keep hands and other body parts clear of moving parts during operation.
- If you experience any unusual noise or resistance while using the die, stop immediately and inspect for issues.

Instructions for Installation and Usage

1. Installation:

- Securely mount the Redding Seating Die in your reloading press according to the manufacturer's instructions.
- Ensure that the seating plug is properly installed and adjusted for the bullet being used.

2. Usage:

- Prepare your cartridge case according to standard reloading procedures.
- Insert the bullet into the cartridge case and position it under the die.
- Slowly operate the press handle to seat the bullet to the desired depth.
- Check the bullet seating depth using a caliper to ensure consistency.
- Once finished, carefully remove the completed cartridges from the press.

Disposal Instructions

- Dispose of any used or damaged components in accordance with local regulations.
- Do not dispose of the die in household waste. Contact your local waste management authority for guidance on proper disposal methods.
- Ensure that any packaging materials are recycled or disposed of properly.

Contact Information for Further Support

For any inquiries regarding the Redding Seating Die or safety concerns, please consult the manufacturer's website or contact customer service through the provided channels.

Conclusion

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience with the Redding Seating Die 17 Mach IV. Always prioritize safety and take necessary precautions while using this product. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk