

STUD MOUNT MONOPODS - LOCKING MONOPOD STUD 5.5-6.5" QUICK KNOB

[Shooting Accessories](#) > [Bipods, Monopods & Accessories](#) > [Monopods](#)

The Accu-Shot Monopods are designed to add stability and provide easy elevation adjustment for bi-pod equipped rifles. The Monopods attach to the rear sling swivel stud of most rifles, or the optional AR-15/M1-A adapter for military type rifles (A2 stocks only). The "Original" Monopod has a lockable elevation adjustment made by rotating the neoprene body of the monopod - each full rotation is equivalent to five inches of movement at 100 yards. This is a well-made, easy to install accessory suitable for shooting off the bench or on the ground. Each model features a lock ring to lock the elevation in place. Quick Knob model allows fast adjustments and has 3.5"-4.65" of elevation. The AI/ASAI Original Monopod fits the Accuracy International AE, AW and AICS stock systems. The Precision Rail Monopod (PRM) from Accu-Shot attaches to a Picatinny rail and has several applications other than monopod use, such as a folding vertical fore grip. It easily folds up and retracts out of the way when not in use. We're offering the PRM with the factory upgraded "Quick Knob" for faster target acquisition. The "Quick Knob" enables the user to make quick adjustments with the push of a button. Depressing the spring loaded button allows your monopod to slide up or down for gross adjustment so that you can find your desired sight picture. Release the button and re-engage the actuator rod threads and rotate the knob for fine adjustment. Available in Standard (3.5" - 4.75"), Mid-Range (4.4" - 5.85"), and Long (5.85" - 6.85") lengths with Quick Knob. Purchase an original Accu-Shot Precision Monopod with the new "Quick Knob" upgrade already installed. Available in Standard (3.65" - 4.75"), Mid-Range (4.75" - 5.85"), and Long (5.7" - 6.85") lengths.



Attributes

- Name: [LOCKING MONOPOD STUD 5.5-6.5" QUICK KNOB](#)
- Manufacturer: [ACCU-SHOT](#)
- Product no.: 749007280
- Mfr. No.: BT06-QK
- Attachment: Stud
- Color: Black
- Height: 5 1/2 to 6 1/2
- Style: Quick Knob
- Delivery weight: 0.272kg
- Shipping height: 25mm
- Shipping width: 114mm
- Shipping length: 193mm
- UPC: 810040220036

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AccuShot Monopods with Quick Knob
- About Us

Safety Instruction Guide for AccuShot Monopods with Quick Knob

Introduction

Thank you for purchasing the AccuShot Monopod with Quick Knob. This product is designed to enhance the stability of bipod equipped rifles and provide easy elevation adjustments. To ensure safe and effective use, please read this safety instruction guide carefully. It contains important information regarding the safe use, installation, and disposal of the monopod.

General Safety Guidelines

- Ensure the monopod is compatible with your rifle before installation.
- Always inspect the monopod for any damage or wear before each use.
- Use the monopod only for its intended purpose as described in this guide.
- Keep the monopod out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

• Installation Safety:

- Ensure the rifle is unloaded before attaching or detaching the monopod.
- Do not force the monopod onto the sling swivel stud. If it does not fit, do not attempt to modify it.

• Usage Safety:

- Always maintain a firm grip on the rifle when using the monopod.
- Adjust the elevation only when the rifle is in a stable position.
- Avoid using the monopod in adverse weather conditions that may affect stability.

• Child Safety:

- Keep the monopod and any associated tools away from children.
- Educate older children about the safe handling of firearms and accessories.

Instructions for Installation and Usage

Installation Steps

1. Prepare the Rifle:

- Ensure the rifle is completely unloaded and pointed in a safe direction.

2. Attach the Monopod:

- Locate the rear sling swivel stud on your rifle.
- Align the monopod with the stud and gently push it into place until it locks securely.

3. Adjust the Elevation:

- To adjust the height, rotate the neoprene body of the monopod. Each full rotation equals five

- inches of movement at 100 yards.
- For the Quick Knob model, press the springloaded button to slide the monopod up or down for gross adjustments. Release the button and rotate the knob for fine adjustments.

4. Check Stability:

- Ensure the monopod is securely attached and stable before taking any shots.

Usage Tips

- Use the monopod in conjunction with a bipod for optimal stability.
- Regularly check the lock ring to ensure the elevation is secure during use.
- Store the monopod in a dry, safe place when not in use to prevent damage.

Disposal Instructions

- Dispose of the monopod in accordance with local regulations.
- Do not dispose of the monopod in general household waste. Instead, check for recycling or hazardous waste disposal options in your area.

Contact Information for Further Support

For any inquiries or support regarding the AccuShot Monopod, please refer to the manufacturer's contact information provided with your product packaging.

By following these guidelines, you can ensure the safe and effective use of your AccuShot Monopod with Quick Knob. Thank you for prioritizing safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at