

# STUD MOUNT MONOPODS - ACCU-SHOT STANDARD RANGE MONOPOD STUD 3.75-4.75" QUICK KNOB

[Shooting Accessories](#) > [Bipods, Monopods & Accessories](#) > [Monopods](#)

The Accu-Shot Monopods are designed to add stability and provide easy elevation adjustment for bi-pod equipped rifles. The Monopods attach to the rear sling swivel stud of most rifles, or the optional AR-15/M1-A adapter for military type rifles (A2 stocks only). The "Original" Monopod has a lockable elevation adjustment made by rotating the neoprene body of the monopod - each full rotation is equivalent to five inches of movement at 100 yards. This is a well-made, easy to install accessory suitable for shooting off the bench or on the ground. Each model features a lock ring to lock the elevation in place. Quick Knob model allows fast adjustments and has 3.5"-4.65" of elevation. The AI/ASAI Original Monopod fits the Accuracy International AE, AW and AICS stock systems. The Precision Rail Monopod (PRM) from Accu-Shot attaches to a Picatinny rail and has several applications other than monopod use, such as a folding vertical fore grip. It easily folds up and retracts out of the way when not in use. We're offering the PRM with the factory upgraded "Quick Knob" for faster target acquisition. The "Quick Knob" enables the user to make quick adjustments with the push of a button. Depressing the spring loaded button allows your monopod to slide up or down for gross adjustment so that you can find your desired sight picture. Release the button and re-engage the actuator rod threads and rotate the knob for fine adjustment. Available in Standard (3.5" - 4.75"), Mid-Range (4.4" - 5.85"), and Long (5.85" - 6.85") lengths with Quick Knob. Purchase an original Accu-Shot Precision Monopod with the new "Quick Knob" upgrade already installed. Available in Standard (3.65" - 4.75"), Mid-Range (4.75" - 5.85"), and Long (5.7" - 6.85") lengths.



Accu-Shot Monopod w/Quick Knob Standard Range 3.75-4.85"

## Attributes

- Name: [ACCU-SHOT STANDARD RANGE MONOPOD STUD 3.75-4.75" QUICK KNOB](#)
- Manufacturer: [ACCU-SHOT](#)
- Product no.: 749007300
- Mfr. No.: BT04-QK
- Attachment: Stud
- Colour: Black
- Height: 3 3/4 to 4 3/4
- Style: Quick Knob
- Delivery weight: 0.204kg
- Shipping height: 25mm
- Shipping width: 127mm
- Shipping length: 196mm
- UPC: 810040220012

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for AccuShot Monopod with Quick Knob
- About Us

# Safety Instruction Guide for AccuShot Monopod with Quick Knob

## Introduction

Thank you for choosing the AccuShot Monopod with Quick Knob, designed for stability and ease of use in various shooting situations. This guide provides essential safety instructions to ensure the safe and effective use of your monopod. Please read this document carefully before using the product.

## General Safety Guidelines

- Ensure that the monopod is used solely for its intended purpose as a support for cameras and other equipment.
- Always inspect the monopod for any visible damage before use. Do not use if damaged.
- Keep the monopod out of reach of children and pets to prevent accidents.
- When using the monopod outdoors, be aware of your surroundings to avoid tripping hazards.
- Follow all local regulations regarding the use of monopods in public spaces.

## Specific Safety Precautions for Use

- **Stability:** Ensure that the monopod is firmly planted on the ground before attaching any equipment.
- **Weight Limit:** Do not exceed the weight limit of the monopod. Refer to the product specifications for details.
- **Adjustments:** Make adjustments to the height of the monopod carefully and only when it is not supporting any equipment.
- **Quick Knob:** Ensure that the Quick Knob is securely fastened before use to prevent accidental release.
- **Weather Conditions:** Avoid using the monopod in extreme weather conditions, such as heavy rain or strong winds, which may compromise stability.

## Instructions for Installation and Usage

1. **Unpacking:** Carefully remove the monopod from its packaging, ensuring that all components are included.
2. **Extending the Monopod:**
  - Grasp the monopod firmly.
  - Twist the Quick Knob counterclockwise to unlock the height adjustment.
  - Extend the monopod to your desired height (between 3.75 to 4.75 inches).
  - Twist the Quick Knob clockwise to secure the monopod at the desired height.
3. **Attaching Equipment:**
  - Ensure the Quick Knob is locked before attaching any camera or equipment.
  - Attach the equipment securely to the monopod's stud attachment.
4. **Using the Monopod:**
  - Position the monopod on a flat, stable surface.
  - Use the monopod to support your camera or equipment while shooting.
  - Always keep one hand on the camera or equipment for additional support.
5. **Dismantling:**
  - When finished, carefully remove the camera or equipment.
  - Twist the Quick Knob counterclockwise to unlock and retract the monopod.
  - Store the monopod in a safe place when not in use.

## **Disposal Instructions**

- Dispose of the monopod according to local regulations regarding plastic and metal waste.
- If the monopod is damaged beyond repair, please recycle the materials where possible.

## **Contact Information for Further Support**

For any inquiries regarding safety or product issues, please contact the manufacturer directly. Ensure you have the product information ready for reference.

Thank you for following these safety instructions. Enjoy using your AccuShot Monopod with Quick Knob responsibly!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)