

STUD MOUNT MONOPODS - LOCKING MONOPOD STUD 4.75-5.75" QUICK KNOB

[Shooting Accessories](#) > [Bipods, Monopods & Accessories](#) > [Monopods](#)

The Accu-Shot Monopods are designed to add stability and provide easy elevation adjustment for bi-pod equipped rifles. The Monopods attach to the rear sling swivel stud of most rifles, or the optional AR-15/M1-A adapter for military type rifles (A2 stocks only). The "Original" Monopod has a lockable elevation adjustment made by rotating the neoprene body of the monopod - each full rotation is equivalent to five inches of movement at 100 yards. This is a well-made, easy to install accessory suitable for shooting off the bench or on the ground. Each model features a lock ring to lock the elevation in place. Quick Knob model allows fast adjustments and has 3.5"-4.65" of elevation. The AI/ASAI Original Monopod fits the Accuracy International AE, AW and AICS stock systems. The Precision Rail Monopod (PRM) from Accu-Shot attaches to a Picatinny rail and has several applications other than monopod use, such as a folding vertical fore grip. It easily folds up and retracts out of the way when not in use. We're offering the PRM with the factory upgraded "Quick Knob" for faster target acquisition. The "Quick Knob" enables the user to make quick adjustments with the push of a button. Depressing the spring loaded button allows your monopod to slide up or down for gross adjustment so that you can find your desired sight picture. Release the button and re-engage the actuator rod threads and rotate the knob for fine adjustment. Available in Standard (3.5" - 4.75"), Mid-Range (4.4" - 5.85"), and Long (5.85" - 6.85") lengths with Quick Knob. Purchase an original Accu-Shot Precision Monopod with the new "Quick Knob" upgrade already installed. Available in Standard (3.65" - 4.75"), Mid-Range (4.75" - 5.85"), and Long (5.7" - 6.85") lengths.



Attributes

- Name: [LOCKING MONOPOD STUD 4.75-5.75" QUICK KNOB](#)
- Manufacturer: [ACCU-SHOT](#)
- Product no.: 749007454
- Mfr. No.: BT05-QK
- Attachment: Stud
- Color: Black
- Height: 4 3/4 to 5 3/4
- Style: Quick Knob
- Delivery weight: 0.249kg
- Shipping height: 18mm
- Shipping width: 122mm
- Shipping length: 191mm
- UPC: 810040220029

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AccuShot Monopods with Quick Knob
- About Us

Safety Instruction Guide for AccuShot Monopods with Quick Knob

Introduction

Thank you for choosing the AccuShot Monopod with Quick Knob. This product is designed to enhance the stability and adjustability of your bipod equipped rifles. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the monopod is compatible with your rifle before use.
- Always inspect the monopod for any damage or wear before installation.
- Use the monopod only for its intended purpose as outlined in this manual.
- Keep the monopod out of reach of children and vulnerable individuals.
- Follow all local laws and regulations regarding firearm accessories.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for any recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the recommended weight limit of your monopod.
- Ensure that the locking mechanism is fully engaged before use to prevent accidental collapse.
- Avoid using the monopod on unstable surfaces that may lead to tipping or falling.
- Always maintain a firm grip on the rifle while adjusting the monopod.
- Be cautious of your surroundings and ensure a clear line of sight when using the monopod.
- Regularly check the adjustment knobs and locking mechanisms for proper function.

Instructions for Installation and Usage

1. Installation

- Locate the rear sling swivel stud on your rifle.
- Attach the monopod to the sling swivel stud, ensuring it is securely fastened.
- If applicable, use the AR15/M1A adapter for militarytype rifles (A2 stocks only).
- Verify that the monopod is stable and securely attached before proceeding.

2. Using the Quick Knob

- To adjust the height, depress the springloaded button located on the Quick Knob.
- Slide the monopod up or down to achieve the desired height.
- Release the button to lock the position.
- For fine adjustments, rotate the Quick Knob to engage the actuator rod threads.

3. Adjusting Elevation

- Each full rotation of the neoprene body of the monopod corresponds to five inches of movement at 100 yards.
- Use the lock ring to secure the elevation once the desired height is achieved.

4. Folding and Storing

- To fold the monopod, retract it back to its compact position when not in use.

- Store the monopod in a dry and safe location, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the product in accordance with local regulations for electronic and firearm accessories.
- Do not dispose of the monopod in general waste. Check with your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the use or safety of the AccuShot Monopod, please consult the retailer where you purchased the product or refer to the manufacturer's website for additional support resources.

Thank you for your attention to these safety instructions. Your safety and the safety of others is our top priority. Enjoy your shooting experience with the AccuShot Monopod!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at