

SINCLAIR GENERATION II BENCHREST WINDAGE TOPS - SINCLAIR INTERNATIONAL BENCHREST SHOOTING REST WINDAGE TOP RIGHT HAND

[Shooting Accessories](#) > [Shooting Rests](#) > [Rifle Rests](#)

Our Sinclair Windage Rest Tops have completely lateral movement windage adjustment and all of the upgraded features found on our non-windage rest tops. Our Windage Rest Tops feature 46 inches of adjustment to 100 yards (23 inches at 500 yards) and are tested at the time of manufacture with 17 lbs of forend weight. Available for right and left-handed shooters and includes a one fourth inch - twenty screw to mount to our Sinclair rest post or any other rest post with one fourth inch - twenty mounting threads. The Sinclair Benchrest (B/R) Windage Top is for shooters who shoot Benchrest or those who prefer using owl ear Protektor or Edgewood front sandbags (Edgewood front bags require additional screw kit) and want the convenience of windage adjustability. The forend stop can be positioned to accommodate both fore/aft and left/right stock contact. For an upgrade to even more adjustability, it can be easily replaced with our Competition Forend Stop (#749-101-026). This Rest Top conforms to all NBRSA and IBS Benchrest rules. Available for right and left-handed shooters and include a 1/4"-20 screw to mount to our Sinclair rest posts or any other rest post with 1/4"-20 mounting threads. Bag not included. Must purchase Screw Kit to go with Rest. NOTE: Right handed rest adjusts on the left side and left handed rest adjusts on the right side.



Attributes

- Name: [SINCLAIR INTERNATIONAL BENCHREST SHOOTING REST WINDAGE TOP RIGHT HAND](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749008039
- Mfr. No.: 045600
- Style: Rest Top
- Delivery weight: 1.247kg
- Shipping height: 196mm
- Shipping width: 188mm
- Shipping length: 231mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Sinclair Generation II Benchrest Windage Tops
- About Us

Safety Instruction Guide for Sinclair Generation II Benchrest Windage Tops

Introduction

Thank you for choosing the Sinclair Generation II Benchrest Windage Tops. This product is designed to enhance your shooting experience with precision and adjustability. To ensure your safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the Sinclair Windage Rest Tops are installed correctly before use.
- Inspect the product for any damage or wear before each use. Do not use if damaged.
- Ensure that you are using the product in a safe environment, away from bystanders and potential hazards.
- Follow all local laws and regulations regarding the use of shooting equipment.
- Keep the product out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure a clear line of sight when shooting.

Specific Safety Precautions for Use

- Use the Sinclair Windage Rest Tops only with compatible rest posts that have 1/4"20 mounting threads.
- Ensure that the forend stop is properly positioned to prevent accidental movement during use.
- Adjust the windage settings only when the firearm is safely secured and pointed in a safe direction.
- Do not exceed the recommended weight limit of 17 lbs for the forend when using the rest tops.
- Always wear appropriate safety gear, such as eye and ear protection, while shooting.
- If you encounter any issues during use, cease operation immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation

- Gather all necessary tools, including a 1/4"20 screw (included).
- Locate the mounting threads on your Sinclair rest post.
- Align the Sinclair Windage Rest Top with the mounting threads.
- Securely attach the rest top using the 1/4"20 screw provided.
- Ensure that the installation is tight and stable before proceeding.

2. Usage

- Position the forend stop to fit your firearm's stock for optimal support.
- Adjust the windage settings as needed for precision shooting.
- Test the stability of the setup before taking any shots.
- Always check that the adjustments are secure before each shooting session.

Disposal Instructions

- Dispose of the Sinclair Windage Rest Tops in accordance with local regulations.
- If the product is damaged beyond repair, consider recycling materials where possible.
- Do not dispose of the product in household waste.

Contact Information for Further Support

For any questions or concerns regarding the Sinclair Generation II Benchrest Windage Tops, please refer to the manufacturer's website or customer service for assistance. Ensure you have your product details on hand for a more efficient response.

By following these guidelines and instructions, you can ensure a safe and enjoyable shooting experience with your Sinclair Windage Rest Tops. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk