

ANTI CANT DEVICE - MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Anti-Cant Devices](#)

Stay On Target, Shot After Shot

Gives an instant check to make sure the gun is perfectly level for every shot, so every shot goes where it's aimed. If you sighted in carefully at 100 yards with the crosshairs level, then canted the gun just six degrees you'd move the next shot over 1/2". Not much, but enough to completely miss a small target, or wound a larger one. The problem gets worse at longer ranges. Clamp the ACD on the scope tube where it's visible to the non-sighting eye.



Attributes

- Name: [MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE](#)
- Manufacturer: [MOUNTING SOLUTIONS PLUS](#)
- Product no.: 749008955
- Mfr. No.: ACD 34MM BLACK
- Finish: Black
- Tube Size: 34mm
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 109mm
- Shipping length: 142mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE Safety Instruction Guide](#)
- [About Us](#)

ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE Safety Instruction Guide

Introduction

Thank you for choosing the ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE. This device is designed to ensure that your firearm is perfectly level for every shot, helping to improve accuracy and prevent misses. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure the product is used in accordance with all applicable laws and regulations.
- Always check the device for any signs of damage before use.
- Keep the device out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before attaching or adjusting the device.
- Do not use the device if it appears damaged or malfunctioning.
- Avoid using the device in extreme weather conditions that could affect its functionality.
- Always use the device in a safe and controlled environment.

Instructions for Installation and Usage

1. Installation:

- Clamp the ANTI CANT DEVICE on the scope tube where it is visible to the nonsighting eye.
- Ensure that the device is securely attached and does not obstruct the view through the scope.

2. Usage:

- Before taking a shot, check the level indicator on the device to confirm that the firearm is level.
- If the device indicates that the firearm is canted, adjust your position or the firearm until the indicator shows that it is level.
- After confirming that the firearm is level, proceed to take your shot.

Disposal Instructions

- Dispose of the product in accordance with local regulations for electronic waste and materials.
- Do not dispose of the product in regular household waste.
- If the product is no longer needed, consider recycling it at a designated facility.

Contact Information for Further Support

For any safety inquiries or additional support regarding the ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE, please refer to the manufacturer's contact information provided with your product.

Thank you for prioritizing safety in your use of the ANTI CANT DEVICE MOUNTING SOLUTIONS PLUS 34MM BLACK ANTI CANT DEVICE. Your attention to these guidelines will help ensure a safe and enjoyable experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk