

PRESS TYPE SHELLHOLDERS - #45 PRESS TYPE SHELLHOLDER

[Reloading](#) > [Shellholders & Shellplates](#)

Hornady Shell Holders are precision machined from solid steel then heat treated to perform flawlessly for the life of the press. They fit all other Hornady accessories (Case Trimmer, Hand-Held Priming Tool, etc.). Hornady steel shell holders also fit most other brands of reloading presses. View Hornady Shellholder Chart.



Attributes

- Name: [#45 PRESS TYPE SHELLHOLDER](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749009884
- Mfr. No.: 390606
- Náboje: 45 Auto (ACP)
- Style: Press Type
- Delivery weight: 0.023kg
- Shipping height: 15mm
- Shipping width: 46mm
- Shipping length: 76mm
- UPC: 090255906066

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Hornady Press Type Shellholder #45
- About Us

Safety Instruction Guide for Hornady Press Type Shellholder #45

Introduction

Thank you for choosing the Hornady Press Type Shellholder #45. This guide provides essential safety instructions and usage guidelines to ensure safe and effective operation of your shellholder. Please read and follow these instructions carefully.

General Safety Guidelines

- Ensure that the shellholder is used only with compatible Hornady accessories and reloading presses.
- Always handle reloading equipment with care to prevent accidents.
- Keep the shellholder and all reloading tools out of reach of children and vulnerable individuals.
- Regularly inspect the shellholder for any signs of wear or damage before use.
- Always follow the manufacturer's instructions for all reloading processes.

Specific Safety Precautions for Use

- Do not exceed the recommended cartridge specifications for the shellholder.
- Use appropriate personal protective equipment (PPE), such as safety glasses, when reloading.
- Ensure that the workspace is clean and free from obstructions to prevent accidents.
- Avoid distractions while using the shellholder to maintain focus.
- If you experience any unusual resistance or difficulty while using the shellholder, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged (if applicable).
- Select the appropriate shellholder for your cartridge (in this case, .45 Auto (ACP)).
- Align the shellholder with the press and securely attach it according to the manufacturer's instructions.

2. Usage:

- Place the cartridge case into the shellholder.
- Follow the specific reloading instructions for your press and the cartridge being used.
- Monitor the reloading process closely and ensure that all components are functioning properly.

Disposal Instructions

- Dispose of any damaged or worn shellholders in accordance with local regulations.
- Do not dispose of the shellholder in general waste; check for recycling options or hazardous waste disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the appropriate contact resources provided by the manufacturer or your retailer. Always ensure that you obtain information from reliable sources.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz