

CASE TRIMMER PILOT - RCBS CASE TRIMMER PILOT 31 CAL

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

Designed with a small taper to help guide the pilot into the case mouth. Sold Separately Rotary Case Trimmer Collets, Trim Pro Manual Case Trimmer and Trim Pro-2 Power Case Trimmer.



Attributes

- Name: [RCBS CASE TRIMMER PILOT 31 CAL](#)
- Manufacturer: [RCBS](#)
- Product no.: 749010579
- Mfr. No.: 9385
- Delivery weight: 0.045kg
- Shipping height: 1mm
- Shipping width: 51mm
- Shipping length: 152mm
- UPC: 076683093851

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for RCBS Case Trimmer Pilot 31 Cal](#)
- [About Us](#)

Safety Instruction Guide for RCBS Case Trimmer Pilot 31 Cal

Introduction

Thank you for choosing the RCBS Case Trimmer Pilot 31 Cal. This guide provides important safety instructions and information to ensure the safe use of this product. Please read this manual carefully before using the product to minimize risks and ensure a safe experience.

General Safety Guidelines

- Always use the product according to the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Do not use the product if it appears to be damaged or malfunctioning.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the work area is clean and free of clutter before using the trimmer.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when operating the trimmer.
- Keep hands and other body parts away from the cutting area while the product is in use.
- Do not force the pilot into the case mouth; if it does not fit easily, check for obstructions.
- Use the product only for its intended purpose; do not modify or alter the trimmer.
- Make sure the trimmer is securely attached to a stable surface before use.
- Do not leave the trimmer unattended while it is in operation.

Instructions for Installation and Usage

1. Installation:

- Find a stable work surface to secure the trimmer.
- Attach the rotary case trimmer collets (sold separately) according to the manufacturer's instructions.
- Ensure that all components are tightened and secure before proceeding.

2. Usage:

- Insert the case into the trimmer.
- Align the RCBS Case Trimmer Pilot 31 Cal with the case mouth.
- Apply gentle pressure to guide the pilot into the case mouth.
- Turn the trimmer handle to begin trimming the case.
- Monitor the trimming process to ensure even trimming and prevent damage to the case.
- Once trimming is complete, carefully remove the case from the trimmer.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the product is no longer usable, consider recycling parts where possible.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any queries related to safety or product support, please reach out to the appropriate EUbased contact for assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk