

SEATER DIE - REDDING SEATER DIE, 17 ACKLEY BEE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

The Redding Standard Seating Die includes a build-in crimping ring and the proper seating plug. These seater dies can be used with or without the crimping engaged.



Attributes

- Name: [REDDING SEATER DIE, 17 ACKLEY BEE](#)
- Manufacturer: [REDDING](#)
- Product no.: 749011061
- Mfr. No.: 92508
- Cartridge: 17 Ackley Bee
- Die Style: Seater Die
- Delivery weight: 0.295kg
- Shipping height: 43mm
- Shipping width: 58mm
- Shipping length: 132mm
- UPC: 611760925085

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for SEATER DIE REDDING SEATER DIE, 17 ACKLEY BEE](#)
- [About Us](#)

Safety Instruction Guide for SEATER DIE REDDING SEATER DIE, 17 ACKLEY BEE

Introduction

Thank you for choosing the SEATER DIE REDDING SEATER DIE, 17 ACKLEY BEE. This product is designed for precision reloading of ammunition. To ensure safe and effective use, please read and follow the safety instructions provided in this guide.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Ensure that the workspace is clean, dry, and welllit.
- Keep the product out of reach of children and unauthorized individuals.
- Do not use the product if it appears damaged or malfunctioning.
- Store the product in a safe place when not in use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate safety gear, including safety glasses and gloves, when using the die.
- Ensure that the die is compatible with the specific cartridge you are using (17 Ackley Bee).
- Engage the crimping ring only when necessary, and ensure it is properly adjusted.
- Do not exceed the recommended load limits for the cartridge.
- Avoid distractions while using the die to maintain focus and precision.
- Use the die only for its intended purpose; do not modify or alter it.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Remove any previous dies from the press.
- Insert the SEATER DIE into the press, ensuring it is tightly secured.
- Adjust the die to the desired seating depth according to your specifications.

2. Usage:

- Prepare your cartridge case by cleaning and inspecting it for any defects.
- Place the cartridge case into the shell holder of the press.
- Insert the bullet into the case mouth.
- Pull the handle to raise the ram, which will seat the bullet.
- Monitor the seating depth closely and make adjustments as necessary.
- Once the bullet is seated, lower the ram and remove the completed cartridge.

Disposal Instructions

- Dispose of any unused or damaged product components in accordance with local regulations.
- Do not dispose of the product in household waste. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the SEATER DIE REDDING SEATER DIE, 17 ACKLEY BEE, please refer to the manufacturer's website or contact customer support for assistance.

Thank you for ensuring safe practices while using this product. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk