

# L.E. WILSON CASE TRIMMER CRANK HANDLE UPGRADE - TRIMMER CRANK HANDLE UPGRADE

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Trimmer Accessories](#)

The Sinclair Crank Handle Upgrade for L.E. Wilson Trimmer Cutters is the same ergonomic replacement crank handle we include with our Carbide Upgrade Kit. Our replacement crank handle will work for all models of L.E. Wilson case trimmers, including 50BMG.



## Attributes

- Name: [TRIMMER CRANK HANDLE UPGRADE](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749011658
- Mfr. No.:
- Caliber: Universal
- Delivery weight: 0.091kg
- Shipping height: 25mm
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

# Table of Contents

- Startpage
- L.E. Wilson Case Trimmer Crank Handle Upgrade Safety Instructions
- About Us

# L.E. Wilson Case Trimmer Crank Handle Upgrade Safety Instructions

## Introduction

Thank you for choosing the L.E. Wilson Case Trimmer Crank Handle Upgrade. This guide provides important safety instructions and usage guidelines to ensure your experience is safe and effective. Please read this document carefully before using the product.

## General Safety Guidelines

- Always ensure the trimmer is turned off and unplugged before performing any maintenance or installation.
- Keep the crank handle upgrade out of reach of children and pets.
- Inspect the crank handle for any signs of damage before each use. Do not use if damaged.
- Use the product only as intended, following all instructions provided in this guide.
- Report any unsafe conditions or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- Ensure your workspace is clean and free from clutter to avoid accidents.
- Wear appropriate safety gear, including safety glasses and gloves, when using the trimmer.
- Do not attempt to modify the crank handle or any other components of the trimmer.
- Always secure the case trimmer on a stable surface before use.
- Be cautious of sharp edges when handling the trimmer and its components.

## Instructions for Installation and Usage

### 1. Installation of the Crank Handle Upgrade:

- Ensure the trimmer is turned off and unplugged.
- Locate the existing crank handle on the trimmer.
- Carefully remove the old crank handle by following the manufacturer's instructions.
- Align the new crank handle with the mounting point and securely attach it.
- Ensure the crank handle is firmly in place before powering on the trimmer.

### 2. Using the Trimmer:

- Plug in the trimmer and ensure it is securely positioned.
- Adjust the settings as needed for your specific trimming requirements.
- Use the crank handle to operate the trimmer smoothly and steadily.
- Monitor the trimming process and stop immediately if any unusual noises or issues occur.

## Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the crank handle or any trimmer components in regular household waste.
- Consider recycling options for the materials, if applicable.

## Contact Information for Further Support

For any questions or concerns regarding the L.E. Wilson Case Trimmer Crank Handle Upgrade, please refer to

the manufacturer's website for support resources and contact information.

Thank you for your attention to these safety instructions. Enjoy using your upgraded crank handle for enhanced performance and efficiency with your L.E. Wilson case trimmer.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)