

COMPETITION STANDARD LENGTH VLD SEATER STEMS - REDDING 338 CALIBER STANDARD VLD COMPETITION SEATING STEM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Redding Competition Standard Length VLD Seater Stems. Stems are 1" long.



Attributes

- Name: [REDDING 338 CALIBER STANDARD VLD COMPETITION SEATING STEM](#)
- Manufacturer: [REDDING](#)
- Product no.: 749013509
- Mfr. No.: 55733
- Caliber: 338 Caliber (.338)
- Cartridge: 30-338 Weatherby
- Delivery weight: 0.023kg
- Shipping width: 83mm
- Shipping length: 152mm
- UPC: 611760557330

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Redding Competition Standard Length VLD Seater Stems
- About Us

Safety Instruction Guide for Redding Competition Standard Length VLD Seater Stems

Introduction

Thank you for choosing the Redding Competition Standard Length VLD Seater Stems. This product is designed for precision reloading of ammunition in the .338 caliber. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide. Your safety is our priority.

General Safety Guidelines

- Always handle reloading equipment with care and follow all safety protocols.
- Ensure that you are of legal age and qualified to use this product.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use this product only for its intended purpose—seating bullets in the .338 caliber cartridge.
- Wear appropriate safety gear, including safety glasses and hearing protection, while reloading.
- Avoid wearing loose clothing or jewelry that could get caught in the equipment.
- Ensure that your workspace is clean and free of obstructions.
- Do not exceed the recommended load specifications for the .338 caliber.
- Follow manufacturer guidelines for the use of compatible components.

Instructions for Installation and Usage

• Installation:

1. Ensure the reloading press is securely mounted and stable.
2. Remove any existing seating stems from the press.
3. Select the Redding Competition Standard Length VLD Seater Stem for the .338 caliber.
4. Install the seater stem into the press according to the manufacturer's instructions.
5. Tighten securely to prevent movement during operation.

• Usage:

1. Prepare your .338 caliber cases and ensure they are clean and free of debris.
2. Set the desired overall cartridge length using the adjustable features of the seating die.
3. Place the bullet on top of the case mouth.
4. Operate the press to seat the bullet into the case, ensuring a consistent depth.
5. Inspect each cartridge after seating to confirm proper bullet alignment and depth.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of reloading materials, including primers and powders, in regular household waste.
- Contact local waste management authorities for proper disposal methods of hazardous materials.

Contact Information for Further Support

For any inquiries or concerns regarding the use of the Redding Competition Standard Length VLD Seater Stems, please refer to the manufacturer's contact information provided with the product packaging.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk