

WFT 2 TRIMMER - LITTLE CROW GUNWORKS. PPC FAMILY TRIM CHAMBER

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmers](#)

The WFT 2 is the next generation of WFT trimmers. The two main improvements are the ability to trim up to 45 caliber and interchange trim chambers. The WFT 2 has a half inch shaft and requires a half inch chuck to drive it. The feature most customers asked for was the ability to interchange trim chambers. Instead of press fitting the trim chambers, like the original WFT, the trim chambers on the WFT 2 are a slight slip fit in bearing with a groove cut for an O-ring which creates a press fit. Changing out trim chambers is accomplished by removing the cutter and pushing out the trim chamber with the knock-out dowel that is provided. Installing the trim chamber is accomplished by setting the trim chamber on a flat surface and steadily pushing the housing onto the trim chamber. Setting the cutter depth is easily adjusted by placing a "master case" in the trim chamber and sliding the cutter up to the case mouth and tightening down the set screws. Trimming is just as precise and clean as with our original trimmer. The trim chamber selection on the WFT 2 is by specific cartridge, but still trims by case family-just order the largest chamber in the family that you intend to trim. This unit and its inserts do not chamfer or deburr the case mouth of the cartridge case as it is trimmed. If you can't find the cartridge you need, please contact our Special Order Department at 800-741-0015



Attributes

- Name: [LITTLE CROW GUNWORKS. PPC FAMILY TRIM CHAMBER](#)
- Manufacturer: [LITTLE CROW GUNWORKS.](#)
- Product no.: 749014417
- Mfr. No.: LCG-WFT2-6MM PPC
- Cartridge: 20 PPC, 22 PPC, 17 PPC, 6mm PPC
- Delivery weight: 0.045kg

Item details

Made in USA

Table of Contents

- Startpage
- WFT 2 Trimmer Safety Instructions
- About Us

WFT 2 Trimmer Safety Instructions

Introduction

Thank you for choosing the WFT 2 Trimmer from Little Crow Gunworks. This product has been designed with safety and efficiency in mind. Please read this safety instruction guide carefully to ensure safe and effective use of the trimmer.

General Safety Guidelines

- Always read and understand the user manual before operating the trimmer.
- Keep the trimmer out of reach of children and vulnerable individuals.
- Inspect the trimmer for any damage before use. Do not use a damaged trimmer.
- Use the trimmer only for its intended purpose as described in the manual.
- Ensure that you are using the correct trim chamber for the cartridge you intend to trim.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while operating the trimmer.
- Do not operate the trimmer in wet or damp conditions to prevent electrical hazards.
- Ensure that all adjustments and settings are secure before operating the trimmer.
- Be aware of your surroundings and ensure that no one is within the immediate area while operating the trimmer.

Specific Safety Precautions for Use

- When changing trim chambers, ensure the trimmer is powered off and unplugged.
- Use the provided knockout dowel to remove the trim chamber safely.
- Always push the trim chamber out gently to avoid damaging the trimmer or the chamber.
- When installing a new trim chamber, ensure it is seated properly before securing it.
- Do not attempt to modify or alter the trimmer in any way.
- If you experience any unusual noises or vibrations while using the trimmer, stop using it immediately and inspect for issues.
- Do not leave the trimmer unattended while it is in operation.

Instructions for Installation and Usage

1. Preparation:

- Ensure you have the correct trim chamber for the cartridge you will be using.
- Place the trimmer on a stable, flat surface.

2. Installing the Trim Chamber:

- Set the trim chamber on the flat surface.
- Align the housing with the trim chamber.
- Steadily push the housing onto the trim chamber until it is securely fitted.

3. Setting the Cutter Depth:

- Insert a "master case" into the trim chamber.
- Slide the cutter up to the case mouth.
- Tighten the set screws to secure the cutter in place.

4. Trimming Process:

- Power on the trimmer and begin trimming the cartridge cases.
- Monitor the trimming process to ensure precision and cleanliness.
- After trimming, remove the cartridge cases and inspect them for any imperfections.

5. Changing Trim Chambers:

- Power off the trimmer and unplug it.
- Remove the cutter.
- Use the knockout dowel to gently push out the trim chamber.
- Follow the installation instructions to replace with a new trim chamber.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the trimmer becomes nonfunctional or is no longer needed, consider recycling it where facilities are available.
- Do not dispose of the trimmer in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or product support, please reach out to the designated support channels provided with your product.

By following these safety instructions, you can ensure a safe and efficient experience with your WFT 2 Trimmer. Thank you for your attention to safety.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu