

MICRO-ADJUSTABLE BULLET SEATER CAP - L.E. WILSON MICRO-ADJUSTABLE BULLET SEATER CAP

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Lets You Make Precise, Repeatable Adjustments in Seating Depth

This Micro-Adjustable Bullet Seater Cap lets you convert any standard chamber-type L.E. Wilson seater die into a precision-adjustable micrometer seater. Simply replace the cap of your standard seater with Wilson's micro-adjustable cap, tighten the setscrew on the new cap, and you are ready to fine-tune your bullet seating depth with remarkable accuracy AND repeatability. The L.E. Wilson Micro-Adjustable seater cap accepts Wilson seating stems (drifts) for .17 to .35 caliber bullets. It allows depth to be adjusted in .001" increments, with a .025" depth change per full rotation. Precision-cut 40 tpi threads aid in holding these precise tolerances and provide uncommonly smooth adjustment. Precision machined from high-grade 303/316 stainless steel. No additional bulk: about the same height as standard L.E. Wilson seater cap. Accepts .17 to .35 caliber Wilson seating stems (drifts). Laser-etched markings will never wear off. Like all L.E. Wilson seater die caps, the Micro-Adjustable Bullet Seater firmly holds bullet and case in perfect alignment as the bullet is seated to help increase concentricity and minimize bullet runout.



Attributes

- Name: [L.E. WILSON MICRO-ADJUSTABLE BULLET SEATER CAP](#)
- Manufacturer: [L.E. WILSON](#)
- Product no.: 749014485
- Mfr. No.: SBSC-MIC
- Delivery weight: 0.227kg
- Shipping height: 38mm
- Shipping width: 38mm
- Shipping length: 97mm
- UPC: 815145021946

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for the MICROADJUSTABLE BULLET SEATER CAP
- About Us

Safety Instruction Guide for the MICROADJUSTABLE BULLET SEATER CAP

Introduction

Thank you for choosing the L.E. Wilson MicroAdjustable Bullet Seater Cap. This product is designed to enhance your reloading experience by providing precision in bullet seating. To ensure safe and effective use, please read and follow this safety instruction guide carefully.

General Safety Guidelines

- Ensure that all reloading equipment is used in accordance with the manufacturer's instructions.
- Always handle reloading components and tools with care to avoid accidents.
- Store all reloading components in a safe, dry place away from children and pets.
- Regularly inspect your reloading equipment for signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the maximum caliber specifications for the MicroAdjustable Bullet Seater Cap.
- Ensure that the seater cap is securely attached to the seater die before use.
- Always wear appropriate safety gear, including safety glasses, when reloading.
- Avoid distractions while reloading to maintain focus and accuracy.
- Keep fingers and hands clear of moving parts during operation.
- Use the product only for its intended purpose as specified by the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Carefully remove the existing cap from your standard L.E. Wilson seater die.
- Align the MicroAdjustable Bullet Seater Cap with the threads of the die.
- Gently screw the cap onto the die until it is handtight.
- Use a tool to tighten the setscrew on the new cap, ensuring it is secure.

2. Usage:

- Insert the desired Wilson seating stem (drift) into the MicroAdjustable Bullet Seater Cap.
- Adjust the seating depth by turning the micrometer cap. Each full rotation changes the depth by .025 inches, with adjustments in .001inch increments.
- Always check the bullet seating depth after adjustments to ensure accuracy.
- Maintain alignment of the bullet and case during the seating process to increase concentricity and minimize bullet runout.

Disposal Instructions

- Dispose of the MicroAdjustable Bullet Seater Cap and any associated materials in accordance with local regulations.
- Do not dispose of the product in general waste if it contains hazardous materials.

Contact Information for Further Support

For any safety inquiries or support regarding the MicroAdjustable Bullet Seater Cap, please refer to the manufacturer's contact resources. Ensure you have your product details ready for efficient assistance.

By following these guidelines and instructions, you can safely enjoy the benefits of the L.E. Wilson MicroAdjustable Bullet Seater Cap. Thank you for prioritizing safety in your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk