

# **MICRO-ADJUST BULLET SEATERS - SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 223 REMINGTON**

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance.



We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance. Available in 12 popular cartridge offerings.

## **Attributes**

- Name: [SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 223 REMINGTON](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749014501
- Mfr. No.: SIN-223R
- Cartridge: 223 Remington
- Die Style: Bullet Seating Dies
- Delivery weight: 0.453kg
- Shipping height: 51mm
- Shipping width: 51mm
- Shipping length: 152mm

## **Item details**

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for MICROADJUST BULLET SEATERS
- About Us

# Safety Instruction Guide for MICROADJUST BULLET SEATERS

## Introduction

Thank you for choosing the Sinclair International MicroAdjust Bullet Seater for your reloading needs. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this guide carefully before using the product.

## General Safety Guidelines

- Ensure that you are familiar with all safety procedures related to reloading ammunition.
- Always use the product in a wellventilated area to avoid inhalation of any dust or particles.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product regularly for any signs of wear or damage.
- Always wear appropriate safety equipment, including safety glasses and gloves, when using this product.
- Follow all local laws and regulations regarding ammunition reloading.

## Specific Safety Precautions for Use

- **Hazard Identification:**

- The MicroAdjust Bullet Seater is designed for precision reloading. Improper use may result in inaccurate ammunition or potential injury.

- **Avoiding Hazards:**

- Always ensure the die is securely mounted before use.
- Do not exceed the recommended adjustments for bullet seating depth.
- Handle all components with care to prevent injury from sharp edges or moving parts.

- **AgeSpecific Warnings:**

- This product is intended for use by adults only. Keep it away from children and individuals who are not trained in firearms and ammunition handling.

## Instructions for Installation and Usage

- **Installation:**

1. Ensure that the reloading press is properly set up and secured.
2. Insert the MicroAdjust Bullet Seater die into the press and tighten it securely.
3. Attach the appropriate seater stem for the bullet you are using.

- **Usage:**

- Adjust the seating depth by turning the die body. Each click represents a .0005" adjustment.
- Use the graduated scale for consistent bullet seating across different sessions.
- After adjusting, perform a test seating with a dummy round to ensure proper depth before proceeding with live ammunition.
- Always doublecheck the seating depth before finalizing your reloads.

## Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not throw the product in regular household waste. Check with your local waste management authority for proper disposal methods.

## Contact Information for Further Support

For any safety inquiries or support regarding the MicroAdjust Bullet Seater, please contact the manufacturer or your local distributor. Ensure that you have the product details ready for reference.

## Conclusion

Following these safety instructions will help you use the Sinclair International MicroAdjust Bullet Seater effectively and safely. Always prioritize safety and compliance with local regulations while reloading ammunition. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)