

MICRO-ADJUST BULLET SEATERS - SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 300 WINCHESTER MAGNUM

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance.



We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance. Available in 12 popular cartridge offerings.

Attributes

- Name: [SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 300 WINCHESTER MAGNUM](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749014506
- Mfr. No.: SIN-3WM
- Cartridge: 300 Winchester Magnum
- Die Style: Bullet Seating Dies
- Delivery weight: 0.532kg
- Shipping height: 32mm
- Shipping width: 70mm
- Shipping length: 121mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for MICROADJUST BULLET SEATERS
- About Us

Safety Instruction Guide for MICROADJUST BULLET SEATERS

Introduction

Thank you for choosing the MICROADJUST BULLET SEATERS from Sinclair International. This guide provides essential safety instructions to ensure the proper and safe use of this product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as a bullet seating die.
- Keep the product out of reach of children and vulnerable individuals.
- Always inspect the product for any visible damage before use.
- Follow all local laws and regulations regarding ammunition reloading and usage.
- Report any unsafe conditions or accidents to the relevant authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when using reloading equipment.
- Do not exceed the recommended bullet seating depth adjustments.
- Ensure that the die is securely mounted before making adjustments.
- Avoid distractions while using the product to maintain focus and ensure safety.
- Use caution when handling components that may be sharp or have moving parts.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is clean and properly set up.
- Carefully remove the MICROADJUST BULLET SEATER from its packaging.
- Attach the bullet seating die to your reloading press following the manufacturer's instructions.
- Tighten securely to prevent movement during use.

2. Usage:

- Adjust the seating depth by turning the die body to achieve the desired depth.
- Use the graduated scale for repeated use with different bullets and seating depths.
- Make adjustments in increments of .0005" for precise bullet seating.
- After making adjustments, ensure that the die is locked in place before proceeding with reloading.

Disposal Instructions

- Dispose of any packaging materials responsibly and in accordance with local waste disposal regulations.
- If the product is no longer usable, follow local guidelines for disposal of metal and nonmetal components.

Contact Information for Further Support

For any inquiries or further support regarding the MICROADJUST BULLET SEATERS, please refer to the manufacturer's contact resources.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk