

MICRO-ADJUST BULLET SEATERS - SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 6MM BRA

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

We gathered our customers ideas and reloading experience with hand dies, and partnered with the experts who make them, to introduce the new Sinclair/L.E. Wilson Micro-Adjust Bullet Seater. It features easy-adjust seating depth capabilities with a simple turn of the die body. Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters are detent-bearing driven with positive "click" increments of .0005" for fast, accurate bullet seating depth adjustments. Here are the details of construction: Each seater stem is custom fitted to the seater body ensuring close tolerance fit Precision-cut threads allow bullet seating depth adjustment in .0005" increments Graduated scale for repeated use with different bullets and seating depths Micro-Adjust "clicks" via stainless springs and stainless ball bearings Constructed of 416 Stainless Steel with precise, laser-etched adjustment scale Made in the USA by L.E. Wilson with 85 years of inline die experience We feel these dies are the finest available in terms of quality, construction, and performance.



Attributes

- Name: [SINCLAIR INTERNATIONAL MICRO-ADJUST BULLET SEATING DIE 6MM BRA](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749014535
- Mfr. No.: SIN-6BRA
- Cartridge: 6 mm BR
- Die Style: Bullet Seating Dies
- Delivery weight: 0.499kg
- Shipping height: 51mm
- Shipping width: 51mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Sinclair International MicroAdjust Bullet Seaters
- About Us

Safety Instruction Guide for Sinclair International MicroAdjust Bullet Seaters

Introduction

Thank you for choosing the Sinclair International MicroAdjust Bullet Seater. This guide provides essential safety instructions, usage guidelines, and disposal information to ensure a safe and effective experience with this product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure safe use of the product by following all instructions provided in this guide.
- Be aware of potential hazards associated with reloading equipment, including the risk of injury and property damage.
- Store the product in a secure location out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you encounter any unsafe conditions or accidents, report them to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses, when using this product.
- Handle all components with care to avoid injury.
- Keep hands and other body parts clear of moving parts during operation.
- Do not exceed the recommended adjustments for bullet seating depth.
- Follow the manufacturer's instructions for proper use and maintenance.
- Ensure that the work area is welllit and free from distractions.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is securely mounted and stable.
- Insert the Sinclair MicroAdjust Bullet Seater into the reloading press according to the manufacturer's instructions.
- Tighten the die securely to prevent movement during operation.

2. Usage:

- Adjust the seating depth by turning the die body clockwise or counterclockwise until the desired depth is achieved.
- Use the graduated scale for repeated use with different bullets and seating depths.
- After adjustments, ensure that the die is securely locked in place.
- Test the seating depth with a dummy round before proceeding with live ammunition.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check with local waste management authorities for proper disposal methods for metal and plastic components.

Contact Information for Further Support

For safety inquiries, product support, or to report unsafe conditions, please reach out to the designated EU contact point associated with this product.

Thank you for prioritizing safety while using the Sinclair International MicroAdjust Bullet Seater. Your adherence to these guidelines ensures a safer reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk