

PRO CHUCKER 7 SHELLPLATES - RCBS PRO CHUCKER 7 SHELLPLATE #12

[Reloading](#) > [Shellholders & Shellplates](#)

Shellplates fit the RCBS Pro Chucker 7 Progressive Reloading Press.



Attributes

- Name: [RCBS PRO CHUCKER 7 SHELLPLATE #12](#)
- Manufacturer: [RCBS](#)
- Product no.: 749015698
- Mfr. No.: 88956
- Cartridge: 17 Hornet, 22 Hornet, 22K Hornet
- Delivery weight: 0.023kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 178mm
- UPC: 076683889560

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [PRO CHUCKER 7 SHELLPLATES Safety Instructions Guide](#)
- [About Us](#)

PRO CHUCKER 7 SHELLPLATES Safety Instructions Guide

Introduction

Thank you for choosing the PRO CHUCKER 7 SHELLPLATES, specifically the RCBS PRO CHUCKER 7 SHELLPLATE #12. This guide provides essential safety instructions to ensure the safe and effective use of your shellplates with the RCBS Pro Chucker 7 Progressive Reloading Press. Please read this guide carefully before use.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the shellplates with your reloading press. Follow all instructions to minimize risks.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to this product.
- **Online Shopping:** If purchased online, ensure the retailer meets safety requirements.
- **Special Consumer Focus:** Extra care should be taken when using this product around children and vulnerable individuals.
- **EU Contact Point:** For safety inquiries, refer to the relevant EU-based contact point.
- **Rapid Alerts:** Monitor the EU Safety Gate platform for updates on unsafe products.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using the reloading press.
- Ensure that the shellplates are compatible with your specific cartridge types: 22 Hornet, 17 Hornet, and 22K Hornet.
- Inspect the shellplates for any damage or wear before each use. Do not use damaged shellplates.
- Keep the work area clean and organized to prevent accidents.
- Do not exceed the recommended load specifications for your reloading press and shellplates.
- Store shellplates in a secure location, out of reach of children and pets.
- Avoid distractions while using the reloading press and shellplates.

Instructions for Installation and Usage

1. Installation of Shellplates:

- Ensure the RCBS Pro Chucker 7 is turned off and unplugged before installation.
- Remove any existing shellplate from the reloading press.
- Align the PRO CHUCKER 7 SHELLPLATE #12 with the mounting points on the press.
- Securely fasten the shellplate according to the manufacturer's instructions.
- Doublecheck that the shellplate is firmly attached before use.

2. Using the Shellplates:

- Load the appropriate cartridges into the shellplates as specified: 22 Hornet, 17 Hornet, or 22K Hornet.
- Follow the reloading press instructions for operating the machine safely.
- Monitor the reloading process closely to ensure everything is functioning properly.
- If any irregularities occur, stop using the press immediately and inspect the shellplates.

Disposal Instructions

- Dispose of any damaged or worn shellplates according to local regulations.
- Do not dispose of shellplates in regular household waste.

- Consider recycling options if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the use of the PRO CHUCKER 7 SHELLPLATES, please consult the manufacturer or authorized retailers for assistance. Always ensure you have the latest information regarding safety and usage.

By following these guidelines, you can ensure a safe and effective reloading experience with your PRO CHUCKER 7 SHELLPLATES. Thank you for your attention to safety and proper usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk