

PRO CHUCKER 7 SHELLPLATES - RCBS PRO CHUCKER 7 SHELLPLATE #13

[Reloading](#) > [Shellholders & Shellplates](#)

Shellplates fit the RCBS Pro Chucker 7 Progressive Reloading Press.



Attributes

- Name: [RCBS PRO CHUCKER 7 SHELLPLATE #13](#)
- Manufacturer: [RCBS](#)
- Product no.: 749015699
- Mfr. No.: 88957
- Cartridge: 7.62 x 54 mm Russian
- Delivery weight: 0.211kg
- Shipping height: 6mm
- Shipping width: 89mm
- Shipping length: 89mm
- UPC: 076683889577

Item details

Made in USA

Table of Contents

- Startpage
- PRO CHUCKER 7 SHELLPLATES Safety Instructions
- About Us

PRO CHUCKER 7 SHELLPLATES Safety Instructions

Introduction

Thank you for choosing the PRO CHUCKER 7 SHELLPLATES. This guide provides essential safety instructions to ensure the safe use of this product. Please read this manual thoroughly before using the shellplate to ensure a safe and effective reloading experience.

General Safety Guidelines

- Ensure that the workspace is clean, dry, and welllit before starting any reloading activities.
- Always wear appropriate safety gear, including safety glasses and hearing protection.
- Keep all reloading components, including powders and primers, out of reach of children and pets.
- Follow the manufacturer's instructions for your reloading press and components carefully.
- Be aware of the potential hazards associated with the reloading process, including the handling of explosives and sharp objects.
- If you notice any defects or damage in the shellplate, do not use it and contact the manufacturer for further instructions.

Specific Safety Precautions for Use

- Use only the designated cartridge for the PRO CHUCKER 7 SHELLPLATE #13, which is 7.62 x 54 mm Russian.
- Ensure that the shellplate is correctly installed on the RCBS Pro Chucker 7 Progressive Reloading Press before use.
- Do not exceed the recommended load data provided by powder manufacturers.
- Always check for proper operation before starting a reloading session. Ensure that the shellplate moves freely and is securely attached.
- Handle all reloading components with care and store them safely when not in use.

Instructions for Installation and Usage

1. Installation:

- Unplug the RCBS Pro Chucker 7 Progressive Reloading Press from the power source.
- Remove any existing shellplate from the press by following the manufacturer's instructions.
- Align the PRO CHUCKER 7 SHELLPLATE #13 with the mounting points on the press.
- Securely attach the shellplate using the provided screws or fasteners.
- Ensure that the shellplate is seated properly and moves freely.

2. Usage:

- Plug the reloading press back into the power source.
- Set up your reloading components according to the manufacturer's guidelines.
- Begin the reloading process by following the specific instructions for your press and cartridge.
- Monitor the operation continuously to ensure safe and efficient functioning.

Disposal Instructions

- Dispose of any defective or damaged shellplates in accordance with local regulations.
- Do not throw away the shellplate in regular household waste. Instead, check with local waste management authorities for proper disposal methods.
- Recycle packaging materials when possible.

Contact Information for Further Support

For any questions or concerns regarding the PRO CHUCKER 7 SHELLPLATES, please refer to the manufacturer's website or contact their customer support. Ensure that you have the product details ready for efficient assistance.

Conclusion

By following these safety instructions, you can help ensure a safe and effective reloading experience with your PRO CHUCKER 7 SHELLPLATES. Always prioritize safety and adhere to all guidelines to minimize risks associated with reloading activities. Thank you for your attention to these important safety practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk