

PRO CHUCKER 7 SHELLPLATES - RCBS PRO CHUCKER 7 SHELLPLATE #14

[Reloading](#) > [Shellholders & Shellplates](#)

Shellplates fit the RCBS Pro Chucker 7 Progressive Reloading Press.



Attributes

- Name: [RCBS PRO CHUCKER 7 SHELLPLATE #14](#)
- Manufacturer: [RCBS](#)
- Product no.: 749015700
- Mfr. No.: 88958
- Cartridge: 30-378 Weatherby Magnum, 45-70 Government, 378 Weatherby Magnum, 338-378 Weatherby, 460 Weatherby Mag, 40-65 Winchester
- Delivery weight: 0.212kg
- Shipping height: 4mm
- Shipping width: 102mm
- Shipping length: 102mm
- UPC: 076683889584

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for PRO CHUCKER 7 SHELLPLATES
- About Us

Safety Instruction Guide for PRO CHUCKER 7 SHELLPLATES

Introduction

Thank you for choosing the PRO CHUCKER 7 SHELLPLATE #14. This product is designed for use with the RCBS Pro Chucker 7 Progressive Reloading Press for various cartridges. To ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read this guide carefully.

General Safety Guidelines

- Always use the shellplates in accordance with the manufacturer's instructions.
- Ensure the reloading press is properly maintained and in good working condition before use.
- Keep the shellplates and all reloading equipment out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage on the shellplates before each use.
- Report any unsafe products or accidents to the relevant authorities immediately.

Specific Safety Precautions for Use

- Use only with specified cartridges:
 - 4570 Government
 - 30378 Weatherby Magnum
 - 338378 Weatherby
 - 378 Weatherby Magnum
 - 460 Weatherby Mag
 - 4065 Winchester
- Do not exceed the recommended load specifications for each cartridge.
- Always wear appropriate safety gear, including safety glasses, when using the reloading press.
- Ensure that the work area is clean and free of obstructions to prevent accidents.
- Do not use the shellplates if you notice any cracks, deformities, or other signs of damage.

Instructions for Installation and Usage

1. Installation:

- Ensure the RCBS Pro Chucker 7 is unplugged before installing the shellplate.
- Align the shellplate with the mounting points on the reloading press.
- Secure the shellplate in place according to the manufacturer's instructions.
- Doublecheck that the shellplate is firmly attached before proceeding.

2. Usage:

- Load the appropriate cartridge into the shellplate.
- Follow the reloading press's operating instructions for proper use.
- After reloading, inspect the cartridges for any defects before storage or use.
- Clean the shellplates regularly to maintain performance and longevity.

Disposal Instructions

- Dispose of any damaged or worn shellplates in accordance with local regulations.
- Do not dispose of shellplates in regular household waste.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support regarding the PRO CHUCKER 7 SHELLPLATES, please refer to the manufacturer's contact information provided with the product packaging.

By following these safety instructions, you can ensure a safe and effective reloading experience with your PRO CHUCKER 7 SHELLPLATES. Thank you for your attention to safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk