

# PRO CHUCKER 7 SHELLPLATES - RCBS PRO CHUCKER 7 SHELLPLATE #44

[Reloading](#) > [Shellholders & Shellplates](#)

Shellplates fit the RCBS Pro Chucker 7 Progressive Reloading Press.



## Attributes

- Name: [RCBS PRO CHUCKER 7 SHELLPLATE #44](#)
- Manufacturer: [RCBS](#)
- Product no.: 749015714
- Mfr. No.: 88972
- Cartridge: 500 S&W,338 Marlin Express
- Delivery weight: 0.181kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 102mm
- UPC: 076683889720

## Item details

Made in USA

# Table of Contents

- Startpage
- PRO CHUCKER 7 SHELLPLATES Safety Instruction Guide
- About Us

# PRO CHUCKER 7 SHELLPLATES Safety Instruction Guide

## Introduction

Thank you for choosing the PRO CHUCKER 7 SHELLPLATES. This guide provides essential safety instructions and information to ensure the safe use of this product with the RCBS Pro Chucker 7 Progressive Reloading Press. Please read and follow these instructions carefully.

## General Safety Guidelines

- Ensure that the shellplates are compatible with the RCBS Pro Chucker 7 Progressive Reloading Press before use.
- Always inspect the shellplates for any signs of damage or wear before installation.
- Keep the shellplates out of reach of children and vulnerable individuals.
- Use the shellplates only for the intended cartridges: 500 S&W and 338 Marlin Express.
- Follow all manufacturer instructions for the proper use of the reloading press.
- Report any unsafe products or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when reloading ammunition.
- Ensure that the reloading area is clean and free from distractions.
- Do not exceed the recommended load specifications for the cartridges being used.
- Avoid using damaged or worn shellplates as they may cause malfunctions or accidents.
- Do not attempt to modify the shellplates or the reloading press in any way.
- Store the shellplates in a dry place to prevent rust or corrosion.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the RCBS Pro Chucker 7 is turned off and unplugged.
- Remove any existing shellplates from the press.
- Align the PRO CHUCKER 7 SHELLPLATE #44 with the mounting points on the reloading press.
- Securely fasten the shellplate according to the manufacturer's instructions.

### 2. Usage:

- Load the appropriate cartridge into the shellplate.
- Follow the reloading press instructions for operating the machine safely.
- Monitor the reloading process closely to ensure there are no malfunctions.
- After use, clean the shellplates to remove any debris or residue.

## Disposal Instructions

- Dispose of any damaged or unusable shellplates in accordance with local regulations.
- Do not throw the shellplates in regular household waste.
- Check with local authorities for proper disposal methods for metal products.

## **Contact Information for Further Support**

For any safety inquiries or further support regarding the PRO CHUCKER 7 SHELLPLATES, please refer to the manufacturer's contact information provided on the packaging or the official website.

Thank you for your attention to these safety guidelines. Your safety is our priority.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)