

PRO CHUCKER 7 SHELLPLATES - RCBS PRO CHUCKER 7 SHELLPLATE #48

[Reloading](#) > [Shellholders & Shellplates](#)

Shellplates fit the RCBS Pro Chucker 7 Progressive Reloading Press.



Attributes

- Name: [RCBS PRO CHUCKER 7 SHELLPLATE #48](#)
- Manufacturer: [RCBS](#)
- Product no.: 749015716
- Mfr. No.: 88974
- Cartridge: 338 Norma Mag,338 Lapua Mag
- Delivery weight: 0.136kg
- Shipping height: 6mm
- Shipping width: 102mm
- Shipping length: 171mm
- UPC: 076683889744

Item details

Made in USA

Table of Contents

- Startpage
- PRO CHUCKER 7 SHELLPLATES Safety Instruction Guide
- About Us

PRO CHUCKER 7 SHELLPLATES Safety Instruction Guide

Introduction

Thank you for choosing the PRO CHUCKER 7 SHELLPLATES, specifically the RCBS PRO CHUCKER 7 SHELLPLATE #48. This product is designed to fit the RCBS Pro Chucker 7 Progressive Reloading Press and is compatible with cartridges including 338 Norma Mag and 338 Lapua Mag. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the PRO CHUCKER 7 SHELLPLATES in accordance with the manufacturer's instructions.
- Ensure that the product is compatible with your reloading press before use.
- Keep this product out of reach of children and vulnerable individuals.
- Regularly inspect the shellplates for signs of wear or damage before use.
- Report any unsafe conditions or product failures to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use only the recommended cartridges specified for this shellplate to avoid malfunctions.
- Do not attempt to modify the shellplates or use them for purposes other than intended.
- Wear appropriate safety gear, such as safety glasses, when operating the reloading press.
- Ensure that your workspace is clean and free of obstructions to prevent accidents.
- Follow all safety protocols related to reloading ammunition, including handling and storage procedures.

Instructions for Installation and Usage

1. Installation:

- Ensure that the RCBS Pro Chucker 7 is turned off and unplugged.
- Remove any existing shellplates from the reloading press.
- Align the PRO CHUCKER 7 SHELLPLATE #48 with the mounting points on the press.
- Securely attach the shellplate according to the manufacturer's instructions.
- Doublecheck that the shellplate is firmly in place before proceeding.

2. Usage:

- Load the appropriate cartridge into the shellplate.
- Follow the reloading press instructions for operation.
- Monitor the reloading process for any irregularities or signs of malfunction.
- After use, remove the shellplate and clean it according to the manufacturer's cleaning guidelines.

Disposal Instructions

- Dispose of any damaged or worn shellplates in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal options.
- Ensure that all components are disposed of responsibly to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact information provided with the product packaging. It is important to have access to support for any questions or concerns regarding the safe use of the PRO CHUCKER 7 SHELLPLATES.

By following these safety instructions, you can ensure a safe and effective experience with your PRO CHUCKER 7 SHELLPLATES. Thank you for prioritizing safety in your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk