

MICRO-ADJUST VLD SEATING STEMS - SINCLAIR INTERNATIONAL

MICRO-ADJUST VLD SEATING STEM 6.5MM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

These VLD Seating Stems are made as a direct replacement for the standard stems that come with the Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters. These stems are reamed with a steeper angle and better designed to grip lower on VLD type bullets than the standard stems. For use with VLD Secant, VLD Tangent or Hybrid bullets.

Normal 0 false false false EN-US X-NONE X-NONE MicrosoftInternetExplorer4 /* Style Definitions */ table.MsoNormalTable {mso-style-name:"Table Normal"; mso-tstyle-rowband-size:0; mso-tstyle-colband-size:0; mso-style-noshow:yes; mso-style-priority:99; mso-style-parent:"", mso-padding-alt:0in 5.4pt 0in 5.4pt; mso-para-margin:0in; mso-para-margin-bottom:.0001pt; mso-pagination:widow-orphan; font-size:10.0pt; font-family:"Times New Roman",serif;} These VLD Seating Stems are made as a direct replacement for the standard stems that come with the Sinclair/L.E. Wilson Micro-Adjust Bullet Seaters. These stems are reamed with a steeper angle and better designed to grip lower on VLD type bullets than the standard stems. For use with VLD Secant, VLD Tangent or Hybrid bullets.



Attributes

- Name: [SINCLAIR INTERNATIONAL MICRO-ADJUST VLD SEATING STEM 6.5MM](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749017457
- Mfr. No.: BSD-V65S
- Cartridge: 264/6.5 mm (.264)
- Delivery weight: 0.016kg
- Shipping height: 19mm
- Shipping width: 19mm
- Shipping length: 66mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for MICROADJUST VLD Seating Stems
- About Us

Safety Instruction Guide for MICROADJUST VLD Seating Stems

Introduction

Thank you for choosing the MICROADJUST VLD Seating Stems from Sinclair International. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your product. Please read this document carefully before using the seating stems.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Always handle the seating stems with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check the product for any signs of damage or wear. Do not use if damaged.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the seating stems only with compatible VLD Secant, VLD Tangent, or Hybrid bullets.
- Avoid using the seating stems with bullets not designed for this product.
- Ensure that you are wearing appropriate safety gear, such as safety glasses and gloves, during use.
- When adjusting the seating depth, do so slowly and carefully to avoid damaging the bullets or the seating stems.
- Do not exceed the recommended torque specifications when using tools with the seating stems.

Instructions for Installation and Usage

1. Installation:

- Ensure that your workspace is clean and free of obstructions.
- Remove the existing standard stems from your Sinclair/L.E. Wilson MicroAdjust Bullet Seater.
- Carefully insert the MICROADJUST VLD Seating Stems into the seater, ensuring they are securely in place.
- Doublecheck that the stems are properly aligned and seated.

2. Usage:

- Before loading, verify that the seating stems are correctly installed and functioning.
- Adjust the seating depth according to your specific bullet requirements.
- Load the bullets into the seating stems, ensuring they are positioned correctly.
- Apply gentle pressure to seat the bullets to the desired depth.
- After use, clean the seating stems to remove any debris or residue.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous materials.
- Do not dispose of the product in household waste.
- Consider returning the product to the manufacturer for proper recycling or disposal.

Contact Information for Further Support

For any questions or concerns regarding the MICROADJUST VLD Seating Stems, please reach out to your local distributor or retailer for assistance. Ensure you have the product details ready for faster support.

By following these guidelines, you can ensure a safe and effective experience with your MICROADJUST VLD Seating Stems. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk