

A-TIP SEATING DIE STEMS - 6MM A-TIP 110GR SEATING STEM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Hornady A-Tip Match Bullet Seating stems are profiled to match A-Tip Match bullets. These seating stems offer precise alignment without harming the bullet. Fits all Hornady Bullet Seating Dies.



Attributes

- Name: [6MM A-TIP 110GR SEATING STEM](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749018814
- Mfr. No.: 397139
- Náboje: 243/6 mm (.243)
- Delivery weight: 0.011kg
- Shipping height: 25mm
- Shipping width: 51mm
- Shipping length: 102mm
- UPC: 090255971392

Item details

Made in USA

Table of Contents

- Startpage
- ATIP SEATING DIE STEMS 6MM ATIP 110GR SEATING STEM Safety Instructions
- About Us

ATIP SEATING DIE STEMS 6MM ATIP 110GR SEATING STEM Safety Instructions

Introduction

Thank you for choosing the Hornady ATip Match Bullet Seating Stems. This product is designed to enhance your reloading experience by providing precise alignment for ATip Match bullets. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always wear appropriate safety gear, including eye protection, when reloading.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for wear or damage before use.
- Report any unsafe product conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not exceed the recommended load specifications when using the seating stems.
- Ensure that the seating stem is compatible with your Hornady Bullet Seating Die.
- Avoid using the seating stems with damaged or deformed bullets, as this may cause improper seating and potential hazards.
- Do not attempt to modify or alter the seating stems in any way.
- Use the seating stems in a wellventilated area to minimize exposure to any fumes or dust.

Instructions for Installation and Usage

1. Installation of Seating Stem:

- Ensure that your Hornady Bullet Seating Die is clean and free from debris.
- Carefully remove the existing seating stem from the die by unscrewing it.
- Align the new ATip Seating Stem with the die and screw it in gently until secure.
- Check that the seating stem is properly seated and aligned.

2. Using the Seating Stem:

- Place the bullet into the case mouth and position it under the seating stem.
- Adjust the die to the desired depth of seating according to your specific reloading requirements.
- Slowly and steadily operate the reloading press to seat the bullet into the case.
- Inspect the seated bullet for proper alignment and depth before proceeding with further reloading steps.

Disposal Instructions

- Dispose of any unused or damaged products in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance regarding safety or usage, please consult the relevant authorities or your

local Hornady distributor.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Hornady ATip Match Bullet Seating Stems. Thank you for prioritizing safety in your reloading practices.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz