

A-TIP SEATING DIE STEMS - 6.5MM A-TIP 135/153GR SEATING STEM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Hornady A-Tip Match Bullet Seating stems are profiled to match A-Tip Match bullets. These seating stems offer precise alignment without harming the bullet. Fits all Hornady Bullet Seating Dies.



Attributes

- Name: [6.5MM A-TIP 135/153GR SEATING STEM](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749018815
- Mfr. No.: 397138
- Náboje: 264/6.5 mm (.264)
- Delivery weight: 0.014kg
- Shipping height: 25mm
- Shipping width: 51mm
- Shipping length: 102mm
- UPC: 090255971385

Item details

Made in USA

Table of Contents

- Startpage
- ATIP SEATING DIE STEMS 6.5MM ATIP 135/153GR SEATING STEM Safety Instructions
- About Us

ATIP SEATING DIE STEMS 6.5MM ATIP 135/153GR SEATING STEM Safety Instructions

Introduction

Thank you for choosing the ATIP Seating Die Stems 6.5mm ATIP 135/153gr. These products are designed to enhance your reloading experience by providing precise alignment for ATIP Match bullets. It is essential to follow the safety guidelines outlined in this manual to ensure safe and effective use.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following guidelines:

- Always read the product instructions carefully before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as specified by the manufacturer.
- Inspect the product regularly for any signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

When using the ATIP Seating Die Stems, please observe the following precautions:

- Ensure that the seating stem is compatible with your Hornady Bullet Seating Die.
- Avoid applying excessive force when seating bullets to prevent damage.
- Always wear appropriate safety gear, including eye protection, while reloading.
- Do not attempt to modify or alter the seating stem in any way.
- Store the product in a cool, dry place to prevent corrosion or damage.

Instructions for Installation and Usage

Follow these steps for safe installation and usage of the ATIP Seating Die Stems:

1. Installation:

- Ensure that your Hornady Bullet Seating Die is clean and free from debris.
- Remove any existing seating stem from the die by unscrewing it counterclockwise.
- Take the ATIP Seating Die Stem and carefully insert it into the die.
- Secure the seating stem by screwing it clockwise until it is snug but not overly tight.

2. Usage:

- Adjust the die to the desired seating depth based on your bullet specifications.
- Place a cartridge case in the shell holder of your reloading press.
- Insert the ATIP Match bullet into the case mouth.
- Operate the press to seat the bullet, ensuring that it aligns properly with the seating stem.
- Check the seating depth using a caliper to ensure accuracy.

Disposal Instructions

Proper disposal of the ATIP Seating Die Stems is important for environmental safety:

- Do not dispose of the product in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.
- If the product is damaged or no longer usable, ensure that it is disposed of in accordance with local regulations.

Contact Information for Further Support

For any questions or concerns regarding the ATIP Seating Die Stems, please consult the manufacturer's website or customer service for assistance. Ensure that you have the product details ready for a more efficient response.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your reloading experience with the ATIP Seating Die Stems!

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz