

EDGEWOOD DEAD BOTTOM - EDGEWOOD SHOOTING BAGS

EDGEWOOD DEAD BOTTOM FOR GATER REAR BAG

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

The Edgewood Dead Bottom works to stabilize the rear bag and provide a "dead" bottom stable bag set up. This also enables the shooter to achieve an additional $\frac{3}{4}$ " to $\frac{7}{8}$ " rear bag height. Each Dead Bottom Bag is manufactured from soft suede leather. Dead Bottom Bags do not come filled.



Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGEWOOD DEAD BOTTOM FOR GATER REAR BAG](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 749101014
- Mfr. No.: 7545
- Colour: Tan
- Material: Leather
- Style: Bag Accessory
- Delivery weight: 0.227kg
- Shipping height: 46mm
- Shipping width: 175mm
- Shipping length: 191mm

Item details

Made in USA

Table of Contents

- Startpage
- Edgewood Dead Bottom Shooting Bags Safety Instructions
- About Us

Edgewood Dead Bottom Shooting Bags Safety Instructions

Introduction

Thank you for choosing the Edgewood Dead Bottom Shooting Bags. These bags are designed to enhance your shooting experience by providing stability and support. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure the shooting area is clear of unauthorized personnel.
- Use the shooting bags only for their intended purpose.
- Regularly inspect the bags for signs of wear or damage before each use.
- Do not use the bags if they are damaged or compromised in any way.
- Keep the bags out of reach of children and pets when not in use.
- Store the bags in a dry and clean environment to maintain their quality.

Specific Safety Precautions for Use

- Ensure the shooting bags are placed on a stable surface to prevent slipping.
- Avoid using the bags near sharp objects that could puncture them.
- Do not overload the bags beyond their intended use; they are designed for stabilization, not as weightbearing equipment.
- When adjusting the height of the bags, ensure that your shooting position is stable and secure.
- Always maintain a safe shooting distance from others when using the bags.

Instructions for Installation and Usage

1. Setting Up the Shooting Bags:

- Place the Edgewood Dead Bottom Bag on a stable surface.
- Ensure the bag is positioned correctly to provide the desired height and stability.
- If using multiple bags, arrange them to suit your shooting style and preference.

2. Adjusting the Bag Height:

- The Dead Bottom design allows for an additional height of $\frac{3}{4}$ " to $\frac{7}{8}$ ".
- Adjust the bags as needed to achieve the optimal shooting position.
- Ensure that the bags are securely in place before taking your shot.

3. Using the Bags:

- Position your firearm comfortably on the bags, ensuring it is stable.
- Always aim in a safe direction and follow all standard shooting safety protocols.
- After use, carefully remove the firearm from the bags and store it safely.

Disposal Instructions

- Dispose of the Edgewood Dead Bottom Bags in accordance with local regulations.
- If the bags are damaged, consider recycling the materials if possible.
- Do not burn the bags as they may contain materials that could release harmful substances.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product concerns, please contact our customer support team through the designated channels provided with your product.

Important Note: Always stay updated with safety alerts and recall notices regarding your product. You can check for updates on the EU's Safety Gate platform to ensure your product remains safe for use. Thank you for prioritizing safety and enjoying your shooting experience with the Edgewood Dead Bottom Shooting Bags.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk