

BOLT SHEATH - PROTEKTOR BOLT SHEATH - LIGHT LEATHER

[Shooting Accessories](#) > [Shooting Rests](#) > [Shooting Rest Accessories](#)

The Protektor Bolt Sheath is an economical way to store your bolt in between firing sessions at the range. Sanctioned rifle matches require the removal of your rifle bolt before exiting the firing line. The Protektor bolt sheath enables you to easily insert most rifle bolts, including magnums, and leave the firing line safe with your action clear. It includes a handy belt loop so that you can wear it at all times during your course of fire. Available in light or dark leather.



Attributes

- Name: [PROTEKTOR BOLT SHEATH - LIGHT LEATHER](#)
- Manufacturer: [PROTEKTOR](#)
- Product no.: 749101016
- Mfr. No.: 20A.BB.G
- Delivery weight: 0.068kg
- Shipping height: 23mm
- Shipping width: 46mm
- Shipping length: 208mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for BOLT SHEATH PROTEKTOR BOLT SHEATH LIGHT LEATHER
- About Us

Safety Instruction Guide for BOLT SHEATH PROTEKTOR BOLT SHEATH LIGHT LEATHER

Introduction

Thank you for choosing the Protektor Bolt Sheath. This product is designed to securely store your rifle bolt between firing sessions, ensuring safety and convenience during your shooting activities. Please read this safety instruction guide carefully to understand the proper use and care of your product.

General Safety Guidelines

- Ensure the Protektor Bolt Sheath is used in accordance with the manufacturer's instructions to prevent accidents and injuries.
- Always inspect the sheath for any signs of wear or damage before each use.
- Keep the sheath out of reach of children and vulnerable individuals to prevent misuse.
- Report any unsafe conditions or accidents related to this product to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- Only use the sheath for its intended purpose: storing rifle bolts.
- Ensure that the rifle bolt is completely clear of the action before inserting it into the sheath.
- Do not force a bolt into the sheath; if it does not fit easily, check for compatibility.
- Always wear the sheath on your belt to keep your bolt safely stored while on the firing line.
- Avoid exposing the leather sheath to extreme temperatures or moisture to maintain its integrity.

Instructions for Installation and Usage

1. Inserting the Bolt:

- Hold the sheath firmly in one hand.
- With your other hand, take the rifle bolt and align it with the opening of the sheath.
- Gently insert the bolt into the sheath until it is fully seated.

2. Wearing the Sheath:

- Locate the belt loop on the sheath.
- Slide the sheath onto your belt, ensuring it is secure and easily accessible.
- Adjust the position as needed for comfort and convenience during use.

3. Removing the Bolt:

- To remove the bolt from the sheath, hold the sheath steady.
- Grasp the bolt and pull it out gently, ensuring not to damage the sheath or the bolt.

Disposal Instructions

- Dispose of the sheath responsibly when it is no longer in use.
- If the sheath is damaged or worn out, consider recycling the leather if your local facilities allow it.
- Do not dispose of the sheath in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the Protektor Bolt Sheath, please refer to the manufacturer's website or customer support resources for assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience while staying safe and responsible.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk