

BOLT SHEATH - PROTEKTOR BOLT SHEATH - DARK LEATHER

[Shooting Accessories](#) > [Shooting Rests](#) > [Shooting Rest Accessories](#)

The Protektor Bolt Sheath is an economical way to store your bolt in between firing sessions at the range. Sanctioned rifle matches require the removal of your rifle bolt before exiting the firing line. The Protektor bolt sheath enables you to easily insert most rifle bolts, including magnums, and leave the firing line safe with your action clear. It includes a handy belt loop so that you can wear it at all times during your course of fire. Available in light or dark leather.



Attributes

- Name: [PROTEKTOR BOLT SHEATH - DARK LEATHER](#)
- Manufacturer: [PROTEKTOR](#)
- Product no.: 749101017
- Mfr. No.: 20A.CB
- Delivery weight: 0.091kg
- Shipping height: 8mm
- Shipping width: 51mm
- Shipping length: 201mm

Item details

Made in USA

Table of Contents

- Startpage
- BOLT SHEATH PROTEKTOR BOLT SHEATH DARK LEATHER Safety Instruction Guide
- About Us

BOLT SHEATH PROTEKTOR BOLT SHEATH DARK LEATHER Safety Instruction Guide

Introduction

Thank you for choosing the Protektor Bolt Sheath. This guide provides essential safety instructions for the proper use and maintenance of your bolt sheath. Please read this guide carefully to ensure safe handling and storage of your rifle bolt.

General Safety Guidelines

- Always ensure that the rifle is unloaded before removing or inserting the bolt into the sheath.
- Keep the bolt sheath out of reach of children and vulnerable individuals.
- Inspect the sheath regularly for any signs of wear or damage.
- Do not use the sheath for any purpose other than storing your rifle bolt.
- If you notice any defects, discontinue use immediately and report the issue.

Specific Safety Precautions for Use

- Ensure the bolt is clean and free of debris before inserting it into the sheath.
- Avoid overfilling the sheath with multiple bolts to prevent potential damage or malfunction.
- Do not expose the sheath to extreme temperatures or moisture to maintain its integrity.
- Always secure the sheath with the belt loop when in use to prevent accidental loss.

Instructions for Installation and Usage

1. Inserting the Bolt:

- Ensure the rifle is pointed in a safe direction and is unloaded.
- Remove the bolt from the rifle.
- Carefully insert the bolt into the sheath, ensuring it fits snugly without forcing it.

2. Wearing the Sheath:

- Attach the belt loop to your belt or waistband.
- Ensure that the sheath is securely fastened and does not obstruct your movements.

3. Removing the Bolt:

- When ready to use the rifle, remove the sheath from your belt.
- Carefully extract the bolt from the sheath.
- Reinsert the bolt into the rifle, ensuring it is properly secured.

Disposal Instructions

- Dispose of the bolt sheath in accordance with local regulations for leather products.
- If the sheath is damaged beyond repair, consider recycling the materials if possible.
- Do not dispose of the sheath in regular household waste.

Contact Information for Further Support

For any inquiries related to safety or product issues, please consult the relevant authorities or your retailer for assistance. Always prioritize safety and compliance with local regulations.

By following these guidelines, you can ensure the safe and effective use of your Protektor Bolt Sheath. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk