

SINCLAIR PRIMING TOOL SHELL HOLDERS - SINCLAIR INTERNATIONAL PRIMING TOOL SHELL HOLDER #13 STAINLESS 45 AUTO RIM

[Reloading](#) > [Shellholders & Shellplates](#)

Sinclair Priming Tool Shell Holders are designed to work specifically in your Sinclair Priming Tool. Each shell holder is precision ground from stainless steel for a lifetime of fit and function. Model number is stamped on the top of the shell holder.



Attributes

- Name: [SINCLAIR INTERNATIONAL PRIMING TOOL SHELL HOLDER #13 STAINLESS 45 AUTO RIM](#)
- Manufacturer: [SINCLAIR INTERNATIONAL](#)
- Product no.: 749101039
- Mfr. No.: 105013
- Cartridge: 45 Auto Rim
- Style: Priming Tool
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Sinclair Priming Tool Shell Holders
- About Us

Safety Instruction Guide for Sinclair Priming Tool Shell Holders

Introduction

Thank you for choosing the Sinclair Priming Tool Shell Holder #13 for your 45 Auto Rim needs. This guide provides essential safety instructions to ensure the safe and effective use of this product. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as outlined in this guide.
- Always handle the shell holder with care to avoid injury.
- Store the shell holder in a safe place, out of reach of children and pets.
- Regularly inspect the shell holder for any signs of wear or damage before use.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about any recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when using the priming tool.
- Do not exceed the recommended cartridge specifications for the shell holder.
- Ensure that the priming tool is securely mounted before use.
- Keep your work area clean and free of distractions while using the product.
- Never leave the priming tool unattended while in use.
- Be cautious of any sharp edges on the shell holder during handling.

Instructions for Installation and Usage

1. Installation

- Ensure the priming tool is turned off and unplugged (if applicable).
- Select the appropriate shell holder for your cartridge (in this case, #13 for 45 Auto Rim).
- Align the shell holder with the priming tool's mounting mechanism.
- Securely attach the shell holder by following the manufacturer's instructions.

2. Usage

- Prepare your workspace by ensuring it is clean and welllit.
- Insert the cartridge into the shell holder, ensuring it is seated properly.
- Follow the instructions provided with the priming tool for the priming process.
- After priming, carefully remove the cartridge and inspect it for proper seating.
- Store the shell holder and any unused cartridges safely after use.

Disposal Instructions

- Dispose of the shell holder responsibly in accordance with local regulations.
- Do not dispose of the shell holder in regular household waste if it is damaged or no longer usable.
- Consider recycling options available in your area for metal products.

Contact Information for Further Support

For any questions or concerns regarding the Sinclair Priming Tool Shell Holder, please refer to the manufacturer's website or customer support resources.

By following these safety guidelines, you can ensure a safe and effective experience with your Sinclair Priming Tool Shell Holder. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk