

RUGER® BOLT ACTION TRIGGERS - RU-R TRIGGER

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Do It Yourself Trigger Upgrades For Ruger® Bolt Guns

Easy-to-install, triggers are investment cast from A-2 tool steel, then heat-treated and drawn to Rc 50-55 for long-lasting reliability. Radius ground sear surfaces help eliminate creep and enhance overall smoothness. Adjusts for weight of pull and uses the factory safety with no alterations. RU-MK II™ fits all Ruger M77® MKII™ rifles with 3-position safety. RU-R replaces the non-adjustable trigger in 77/22® and 77/17® rimfire rifles. Will not fit V/T Models with 2 stage trigger.



Attributes

- Name: [RU-R TRIGGER](#)
- Manufacturer: [RIFLE BASIX](#)
- Product no.: 758000010
- Mfr. No.: RU-R BLACK
- Make: Ruger
- Model: 77/17,77/22
- Style: Adjustable
- Delivery weight: 0.045kg
- Shipping height: 15mm
- Shipping width: 94mm
- Shipping length: 157mm
- UPC: 891678000481

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- RUGER® BOLT ACTION TRIGGERS RUR TRIGGER Safety Instruction Guide
- About Us

RUGER® BOLT ACTION TRIGGERS RUR TRIGGER Safety Instruction Guide

Introduction

Thank you for choosing the RUGER® Bolt Action Triggers RUR Trigger. This guide provides essential safety instructions and usage guidelines to ensure the safe and effective operation of your product. Please read this document carefully before installation and use.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following general safety guidelines:

- Always treat firearms and their components as if they are loaded.
- Keep the trigger area clear of obstructions and ensure that no one is in the line of fire.
- Ensure that you are using the trigger in a safe environment, free of distractions.
- Always wear appropriate safety gear, including eye and ear protection, when handling firearms.
- Store the trigger and any associated components securely and out of reach of children and unauthorized users.
- Regularly inspect the trigger for signs of wear or damage before use.

Specific Safety Precautions for Use

When using the RUGER® Bolt Action Triggers RUR Trigger, please follow these specific safety precautions:

- Ensure that the trigger is compatible with your firearm model (RUMK II™ fits all Ruger M77® MKII™ rifles; RUR replaces the nonadjustable trigger in 77/22® and 77/17® rimfire rifles).
- Do not attempt to modify the trigger beyond the manufacturer's specifications.
- Avoid using the trigger if it shows signs of damage or malfunction.
- Always use the factory safety mechanism without any alterations.
- Adjust the weight of pull only when the firearm is in a safe position and not loaded.
- Do not install the trigger while the firearm is loaded or in a potentially unsafe environment.

Instructions for Installation and Usage

Follow these stepbystep instructions to install and use the RUGER® Bolt Action Triggers RUR Trigger safely:

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools and the trigger package.

2. Installation:

- Remove the existing trigger from your firearm according to the manufacturer's instructions.
- Carefully install the RUR Trigger by following these steps:
 - Align the trigger with the mounting points of your firearm.
 - Secure the trigger using the provided screws, ensuring they are tightened properly.
 - Adjust the weight of pull to your preference within the specified range (1½ 3 lb or 0.7 1.4 kg).
- After installation, check that the trigger operates smoothly without any binding.

3. Usage:

- Conduct a function check to ensure the trigger operates correctly:
 - Ensure the safety is engaged and pull the trigger. The firearm should not discharge.
 - Disengage the safety and pull the trigger. The firearm should discharge as intended.
- Always keep your finger off the trigger until you are ready to shoot.

4. PostInstallation:

- Regularly inspect the trigger for any signs of wear or damage.
- Make adjustments to the weight of pull as needed, ensuring safety at all times.

Disposal Instructions

When disposing of the RUGER® Bolt Action Triggers RUR Trigger, please follow these guidelines:

- Dispose of the trigger in accordance with local regulations regarding firearm components.
- If the trigger is damaged beyond repair, ensure it is rendered inoperable before disposal.
- Recycle materials where possible, following local recycling guidelines.

Contact Information for Further Support

For additional information or support regarding the RUGER® Bolt Action Triggers RUR Trigger, please refer to the manufacturer's contact details provided with your product.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe use of your RUGER® Bolt Action Triggers RUR Trigger. Always prioritize safety and compliance with local laws and regulations. Thank you for your attention to these important safety measures.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at