

1911 LANYARD LOOP - SS LANYARD LOOP

[Handgun Parts](#) > [Frame Parts](#) > [Frame Hardware](#) > [Lanyard Loops](#)

Provides Additional Weapon Security and Retention

Replace lost or broken lanyard loops, or add a loop to any 1911 for improved weapon retention. Installs easily to the bottom of the mainspring housing; drill three holes and secure with supplied roll pin. Available blued or stainless to match your pistol. Requires precision drilling with a #36 drill and cross drilling with a #40 drill for installation. Detailed instructions included. Complete housings also available.



Attributes

- Name: [SS LANYARD LOOP](#)
- Manufacturer: [SMITH & ALEXANDER](#)
- Product no.: 849000020
- Mfr. No.: LLSS
- Make: 1911
- Model: Commander, Government, Officers
- Delivery weight: 0.005kg
- Shipping width: 57mm
- Shipping length: 89mm

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- 1911 Lanyard Loop Safety Instruction Guide
- About Us

1911 Lanyard Loop Safety Instruction Guide

Introduction

Thank you for choosing the 1911 Lanyard Loop SS Lanyard Loop. This product is designed to enhance weapon retention by replacing lost or broken lanyard loops or by adding a loop to any 1911 model. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure safe use of the lanyard loop by following all installation and usage instructions.
- Be aware of potential hazards associated with improper installation or use of the product.
- Always check for product recalls and safety notices on official platforms.
- Report any unsafe products or accidents to the relevant authorities.
- If you are purchasing online, ensure that the platform complies with safety requirements.

Specific Safety Precautions for Use

- The lanyard loop is designed for use with 1911 models: Government, Commander, and Officers. Ensure compatibility before installation.
- Use only the recommended drill sizes (#36 for precision drilling and #40 for cross drilling) to avoid damaging the mainspring housing.
- Always wear appropriate safety gear, such as safety goggles and gloves, during installation.
- Keep the product out of reach of children and ensure it is not used as a toy.
- Inspect the lanyard loop regularly for signs of wear or damage. Do not use if damaged.

Instructions for Installation and Usage

1. Preparation:

- Gather the necessary tools: a #36 drill bit, a #40 drill bit, a drill, and the supplied roll pin.
- Ensure the workspace is clean and welllit.

2. Installation Steps:

- Remove the mainspring housing from the 1911.
- Mark the locations for the three holes required for installation.
- Using the #36 drill bit, drill the first hole at the marked location.
- Repeat the drilling process for the remaining two holes.
- After drilling, use the #40 drill bit to cross drill as specified in the instructions.
- Align the lanyard loop with the drilled holes and secure it using the supplied roll pin.
- Reattach the mainspring housing to the 1911.

3. PostInstallation Check:

- Ensure the lanyard loop is securely attached and does not move.
- Test the loop for proper function before using the firearm.

Disposal Instructions

- Dispose of any packaging materials and unused components in accordance with local waste disposal regulations.
- If the lanyard loop is damaged and no longer usable, follow local guidelines for disposing of metal products.

Contact Information for Further Support

For any safety inquiries or further support regarding the 1911 Lanyard Loop, please refer to the manufacturer's website or contact the EUbased support center associated with the product.

Thank you for following these safety instructions. Your safety and the safe handling of your firearm are our top priorities.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at