

SHOTGUN SHELL CATCHERS - BIRCHWOOD CASEY BERETTA A400 PAR TARGET/SPORTING 12GA RIGHT HAND

[Shooting Accessories](#) > [Range Gear](#) > [Shell Catchers & Deflectors](#)

Plastic clip stops cases in the ejection port for the easy removal. No more bending/stooping to pick up cases or losing them to ranges with "If it hits the ground, it's ours" policies. Snaps easily to side of receiver just below the ejection port; snaps off when you need to cycle more than one round, as when shooting doubles.



Attributes

- Name: [BIRCHWOOD CASEY BERETTA A400 PAR TARGET/SPORTING 12GA RIGHT HAND](#)
- Manufacturer: [BIRCHWOOD CASEY](#)
- Product no.: 869000005
- Mfr. No.: BC-41024
- Style: Brass Catcher
- Delivery weight: 0.023kg
- Shipping height: 25mm
- Shipping width: 74mm
- Shipping length: 76mm
- UPC: 029057410242

Item details

Made in USA

Table of Contents

- Startpage
- SHOTGUN SHELL CATCHERS BIRCHWOOD CASEY BERETTA A400 PAR TARGET/SPORTING 12GA RIGHT HAND Safety Instruction Guide
- About Us

SHOTGUN SHELL CATCHERS BIRCHWOOD CASEY BERETTA A400 PAR TARGET/SPORTING 12GA RIGHT HAND Safety Instruction Guide

Introduction

Thank you for choosing the Birchwood Casey Shotgun Shell Catchers for your Beretta A400 Par Target/Sporting 12GA Right Hand shotgun. This product is designed to enhance your shooting experience by preventing spent shell cases from being lost or left on the ground. It is important to use this product safely and effectively. Please read this guide carefully to understand the safety precautions, installation instructions, and proper usage of the shell catcher.

General Safety Guidelines

To ensure your safety and the safety of others while using the Birchwood Casey Shotgun Shell Catchers, please follow these general safety guidelines:

- Always handle firearms with care and follow all safety rules.
- Ensure that the shotgun is unloaded before attaching or removing the shell catcher.
- Use the shell catcher only for its intended purpose.
- Regularly inspect the shell catcher for signs of wear or damage before each use.
- Keep the shell catcher clean and free from debris to ensure proper function.
- Do not attempt to modify the shell catcher in any way.
- Store the shell catcher in a safe place when not in use.

Specific Safety Precautions for Use

When using the Birchwood Casey Shotgun Shell Catchers, please observe the following safety precautions:

- **Avoid Obstruction:** Ensure that the shell catcher does not obstruct the ejection port or interfere with the operation of the shotgun.
- **Proper Attachment:** Make sure the shell catcher is securely attached to the side of the receiver just below the ejection port before use.
- **Cycle Multiple Rounds:** Be aware that the shell catcher snaps off easily when cycling more than one round, such as when shooting doubles. Ensure that you are prepared for this action.
- **Monitor Surroundings:** Be aware of your surroundings and ensure that you are in a safe shooting environment.
- **Supervise Young Shooters:** If children or inexperienced shooters are present, supervise them closely and ensure they understand the importance of firearm safety.

Instructions for Installation and Usage

Follow these steps for the proper installation and usage of the Birchwood Casey Shotgun Shell Catchers:

1. Installation:

- Ensure the shotgun is unloaded and pointed in a safe direction.
- Locate the ejection port on the side of the receiver.
- Align the plastic clip of the shell catcher with the side of the receiver just below the ejection port.
- Press the shell catcher firmly against the receiver until it snaps into place. Ensure it is securely attached.

2. Usage:

- Once installed, the shell catcher will stop spent cases in the ejection port, allowing for easy removal.
- When you are ready to shoot, ensure that the shell catcher remains in place.
- If you need to cycle more than one round, gently pull the shell catcher away from the receiver to remove it.
- After shooting, collect the spent cases from the shell catcher for proper disposal.

Disposal Instructions

Proper disposal of the Birchwood Casey Shotgun Shell Catchers is important for environmental safety:

- If the shell catcher becomes damaged or is no longer usable, dispose of it in accordance with local regulations for plastic waste.
- Recycle the shell catcher if possible, following your local recycling guidelines.
- Do not dispose of the shell catcher in a manner that could harm the environment or wildlife.

Contact Information for Further Support

For any questions or concerns regarding the Birchwood Casey Shotgun Shell Catchers, please refer to the product packaging or the manufacturer's website for contact information. It is important to have a reliable point of contact for any safety inquiries or assistance you may need.

By following these safety instructions, you can ensure a safe and enjoyable experience while using your Birchwood Casey Shotgun Shell Catchers. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk