

RUGER® AMERICAN TRIGGERS - TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Self-contained, 100% drop-in trigger is ready to install in your Ruger American Rifle® for an exceptionally smooth, crisp, trigger pull. Pull weight is factory set at crisp three pounds and you can set it yourself to any pull weight you'd like from 1.5 to 4 pounds. Lightweight 6061 T6 aluminum housing is anodized for extra durability. The trigger is CNC machined on the most cutting edge robotic machines available. The sear is EDM cut and Teflon-nickel coated for maximum lubricity. The whole unit has been designed for easy installation and manufactured using Timney's stringent specifications for a lifetime of trouble free service.



Attributes

- Name: [TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER](#)
- Manufacturer: [TIMNEY](#)
- Product no.: 883000058
- Mfr. No.: 640R
- Model: American
- Style: Rimfire
- Weapon type: Ruger
- Delivery weight: 0.088kg
- Shipping height: 38mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950006403

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for RUGER® AMERICAN TRIGGERS TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER
- About Us

Safety Instruction Guide for RUGER® AMERICAN TRIGGERS TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER

Introduction

Thank you for choosing the RUGER® AMERICAN TRIGGERS TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of your trigger. Please read this document carefully and follow all instructions to enhance your safety and the performance of your product.

General Safety Guidelines

- Ensure that the trigger is suitable for your specific model of Ruger American Rifle® before installation.
- Always treat your firearm as if it is loaded, even when you believe it is not.
- Keep the firearm pointed in a safe direction at all times.
- Store the trigger and firearm securely, out of reach of unauthorized users, especially children.
- Regularly inspect the trigger for any signs of wear or damage before each use.
- Follow all local laws and regulations regarding firearm modifications and safety.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for use by individuals under the age of 18 without adult supervision.
- **Installation Precautions:** Ensure that you are in a safe environment when installing the trigger, free from distractions.
- **Handling:** Always wear appropriate safety gear, including eye protection, when handling firearms and firearm parts.
- **Testing:** After installation, test the trigger in a safe environment before use to ensure proper function.
- **Emergency Procedures:** Familiarize yourself with emergency procedures in case of accidental discharge or malfunction.

Instructions for Installation and Usage

1. Preparation:

- Ensure your Ruger American Rifle® is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a screwdriver and any other required equipment.

2. Installation Steps:

- Remove the action from the stock of the rifle.
- Locate the original trigger assembly and carefully detach it from the rifle.
- Take the TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER and position it in the trigger housing.
- Secure the trigger in place according to the manufacturer's specifications.
- Reassemble the rifle by placing the action back into the stock.

3. Adjusting Pull Weight:

- The trigger comes factory set to three pounds. If you wish to adjust the pull weight, follow these steps:
 - Locate the adjustment screw on the trigger assembly.

- Use a screwdriver to turn the screw clockwise to increase the pull weight or counterclockwise to decrease it.
- Test the trigger pull after each adjustment to ensure it meets your preference.

4. Final Check:

- Once installed, conduct a function check of the firearm in a safe environment.
- Ensure that the trigger operates smoothly without any hindrance.

Disposal Instructions

- Dispose of any packaging materials responsibly and in accordance with local waste management regulations.
- If the trigger becomes damaged or is no longer functional, do not attempt to repair it. Dispose of it in a safe manner to prevent unauthorized use.

Contact Information for Further Support

For any inquiries or concerns regarding the RUGER® AMERICAN TRIGGERS TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER, please refer to the manufacturer's contact information provided at the point of purchase or on the official website.

By following this safety instruction guide, you can ensure the safe and effective use of your RUGER® AMERICAN TRIGGERS TIMNEY RUGER® AMERICAN RIMFIRE® TRIGGER. Always prioritize safety and adhere to all guidelines for a responsible and enjoyable shooting experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk