

RUGER PRECISION® RIMFIRE 2-STAGE TRIGGERS - TIMNEY RUGER PRECISION® STRAIGHT TRIGGER 2-STAGE 8OZ/1LB

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

A Precision Trigger for Your Ruger Rimfire Rifle

The discipline of precision-rimfire shooting has taken off in recent years, as manufacturers roll out rifle platforms capable of providing consistent, accurate performance with the .22 LR round. However, every element of a precision-rimfire system counts, and the Timney RPR Rimfire Trigger is a two-stage design that'll improve your shooting skills with ease. Each Timney RPR Rimfire Trigger drops into any factory Ruger Precision Rimfire Rifle with ease, providing a smooth, crisp, two-stage trigger pull without any gunsmithing needed. The trigger comes from the factory with a half-pound first stage and a one-pound second stage. The first stage is user-adjustable from 8 ounces to a full pound, while the second stage is adjustable from 8 ounces to two pounds. Both curved and straight trigger shoes are available. The entire Timney RPR Rimfire Trigger unit comes in a self-contained housing machined from 6061-T6 aluminum alloy. The sear is wire-EDM cut, heat-treated and Teflon-nickel coated to ensure consistent performance throughout the life of your rifle.



Attributes

- Name: [TIMNEY RUGER PRECISION® STRAIGHT TRIGGER 2-STAGE 8OZ/1LB](#)
- Manufacturer: [TIMNEY](#)
- Product no.: 883000122
- Mfr. No.: 649ST
- Model: Precision Rimfire
- Style: 2-Stage,Drop-In,Straight
- Weapon type: Ruger
- Delivery weight: 0.1kg
- Shipping height: 38mm
- Shipping width: 89mm
- Shipping length: 191mm
- UPC: 081950649174

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for RUGER PRECISION® RIMFIRE 2STAGE TRIGGERS
- About Us

Safety Instruction Guide for RUGER PRECISION® RIMFIRE 2STAGE TRIGGERS

Introduction

Thank you for choosing the Timney RPR Rimfire Trigger for your Ruger Precision Rimfire Rifle. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your trigger. Please read this document carefully before installation and use.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the Timney RPR Rimfire Trigger. This product is designed for precision shooting and should be used responsibly.
- **Enhanced Recalls:** Stay informed about any recalls that may affect your product. Follow the instructions provided in recall notices.
- **Online Shopping:** If purchased online, ensure that the platform complies with safety requirements and offers the same protections as physical stores.
- **Special Consumer Focus:** Extra care should be taken when this product is used around children or vulnerable individuals.
- **EU Contact Point:** For any safety inquiries, refer to the designated EU contact point associated with this product.
- **Rapid Alerts:** Regularly check the EU's Safety Gate platform for updates on product safety.

Specific Safety Precautions for Use

- **Read the Manual:** Always read the manufacturer's manual before using the product.
- **Check Compatibility:** Ensure that the Timney RPR Rimfire Trigger is compatible with your Ruger Precision Rimfire Rifle.
- **Inspect Before Use:** Regularly inspect the trigger for any signs of damage or wear.
- **Keep Away from Children:** Store the trigger and all related components out of reach of children.
- **Use Proper Ammunition:** Only use .22 LR ammunition as specified for this product.
- **Avoid Modifications:** Do not modify the trigger or any components, as this may compromise safety and performance.
- **Follow Local Laws:** Adhere to all local laws and regulations regarding firearm and accessory use.

Instructions for Installation and Usage

Installation

1. **Gather Tools:** Ensure you have the necessary tools for installation, including screwdrivers and any other required equipment.
2. **Unload the Rifle:** Always ensure the rifle is unloaded before beginning installation.
3. **Remove the Old Trigger:** Follow the manufacturer's instructions to safely remove the existing trigger from your Ruger Precision Rimfire Rifle.
4. **Install the Timney RPR Rimfire Trigger:**
 - Carefully insert the new trigger into the trigger housing.
 - Align the trigger with the mounting holes.
 - Secure the trigger using the provided screws, ensuring a tight fit.
5. **Adjust the Trigger:**
 - Set the first stage to your preferred weight (between 8 ounces to 1 pound).
 - Adjust the second stage as needed (between 8 ounces to 2 pounds).
6. **Test the Trigger:** Before using the rifle, perform a function check to ensure the trigger operates smoothly and safely.

Usage

- **Practice Safe Handling:** Always treat your firearm as if it is loaded. Keep the muzzle pointed in a safe direction.
- **Use a Proper Shooting Position:** Ensure you are in a stable shooting position to maintain control while shooting.
- **Follow Range Rules:** Adhere to all rules and regulations of the shooting range or location where you are using the rifle.
- **Regular Maintenance:** Clean and maintain the trigger and rifle according to the manufacturer's recommendations to ensure optimal performance.

Disposal Instructions

- **Dispose of Responsibly:** When disposing of old triggers or parts, follow local regulations for hazardous waste disposal.
- **Recycle Materials:** If possible, recycle materials such as metal and plastic components.

Contact Information for Further Support

For any questions, concerns, or support regarding the Timney RPR Rimfire Trigger, please refer to the manufacturer's official contact points. Always keep this guide for future reference and ensure that you stay informed about product safety updates.

Thank you for prioritizing safety while enjoying your precision shooting experience with the Timney RPR Rimfire Trigger.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk