

TIMNEY ALPHA TRIGGER FOR GLOCK® GEN 3/4 G17/19/34 STRAIGHT 3 LBS



Attributes

- Name: [TIMNEY ALPHA TRIGGER FOR GLOCK® GEN 3/4 G17/19/34 STRAIGHT 3 LBS](#)
- Manufacturer:
- Product no.: 883000154
- Mfr. No.: ALPHA GLOCK 3-4
- Finish: Black
- Model: 23,34,19,Gen 4,Gen 3,17,22
- Style: Flat
- Weapon type: Glock
- Delivery weight: 0.15kg
- Shipping height: 51mm
- Shipping width: 127mm
- Shipping length: 197mm
- UPC: 081950613403

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for ALPHA TRIGGER FOR GLOCK® GEN 3/4 G17/19/34
- About Us

Safety Instruction Guide for ALPHA TRIGGER FOR GLOCK® GEN 3/4 G17/19/34

Introduction

Thank you for choosing the Timney Alpha Trigger for your Glock handguns. This guide provides important safety instructions and guidelines to ensure the safe use of your product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure the product is used only with compatible Glock models (G17, G19, G22, G23, G34, Gen 3, Gen 4).
- Always handle firearms with care and follow standard safety practices.
- Keep the trigger and all firearm parts out of reach of children and unauthorized users.
- Regularly inspect your firearm and the trigger for any signs of wear or damage.
- Do not attempt to modify the trigger or any firearm components beyond the manufacturer's specifications.
- If you experience any issues with the trigger or firearm, cease use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Only use the Timney Alpha Trigger in a safe and controlled environment.
- Always ensure the firearm is unloaded before installing or handling the trigger.
- Be aware of your surroundings and ensure that you are in a safe area when using your firearm.
- Use appropriate eye and ear protection while shooting.
- Do not place your finger on the trigger until you are ready to shoot.
- Always point the firearm in a safe direction, away from yourself and others.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is unloaded.
- Gather the necessary tools for installation (screwdriver, etc.).

2. Installation Steps:

- Remove the slide and frame from your Glock handgun.
- Follow the manufacturer's instructions to remove the existing trigger mechanism.
- Install the Timney Alpha Trigger by inserting the Teflonnickeltreated trigger bar and sear into the appropriate slots.
- Secure the trigger blade in place with the provided components.
- Reassemble the firearm, ensuring all parts are correctly fitted.

3. PostInstallation Checks:

- Conduct a function check to ensure the trigger operates correctly.
- Verify that the trigger pull weight is approximately three pounds.
- Ensure all safety mechanisms are functioning as intended.

4. Usage:

- When using your firearm, maintain a proper grip and stance.
- Practice regularly to become familiar with the trigger's performance and characteristics.
- Always adhere to local laws and regulations regarding firearm use.

Disposal Instructions

- Dispose of any packaging materials according to local waste management regulations.
- If you need to dispose of the trigger or any firearm components, consult local guidelines for hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the Timney Alpha Trigger or its installation, please refer to the manufacturer's website or contact their customer support.

It is important to stay informed about any product recalls or safety notices. Regularly check the EU's Safety Gate platform for updates on unsafe products.

Thank you for prioritizing safety and compliance with these guidelines. Enjoy your enhanced shooting experience with the Timney Alpha Trigger.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk