

# WINCHESTER 70 TRIGGERS - TIMNEY WINCHESTER 70, BLUE TRIGGER

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

## Gives A Clean, Crisp Break, Fully Adjustable, Helps Improve Accuracy

Adjustable, Featherweight-style, single-stage, replacement triggers for popular bolt action rifles deliver clean, crisp trigger pulls that help improve accuracy. Precision machined and hardened internal parts for maximum reliability. Adjustable for weight of pull (1-1/2-4 lb.), creep and overtravel. Lock nuts hold settings. Winchester 70 fits Pre-and Post-64 Model 70; Model 54 requires gunsmith fitting. Uses factory safety. Winchester 70 MOA fits Winchester Model 70s with MOA trigger group made since 2008. Adjustable pull weight from 1-3 pounds. Adjustable for over-travel.



## Attributes

- Name: [TIMNEY WINCHESTER 70, BLUE TRIGGER](#)
- Manufacturer: [TIMNEY](#)
- Product no.: 883400170
- Mfr. No.: 401
- Model: 70
- Style: Adjustable
- Weapon type: Winchester
- Delivery weight: 0.045kg
- Shipping height: 10mm
- Shipping width: 79mm
- Shipping length: 104mm
- UPC: 081950004010

## Item details

Made in USA

US export classification: 0A501.c

# Table of Contents

- Startpage
- WINCHESTER 70 TRIGGERS TIMNEY WINCHESTER 70 Safety Instruction Guide
- About Us

# WINCHESTER 70 TRIGGERS TIMNEY WINCHESTER 70 Safety Instruction Guide

## Introduction

Thank you for choosing the WINCHESTER 70 TRIGGERS TIMNEY WINCHESTER 70, BLUE TRIGGER. This product is designed to enhance your shooting experience by providing adjustable, featherweightstyle, singlestage triggers for popular bolt action rifles. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

## General Safety Guidelines

- Always handle firearms and accessories with care.
- Ensure that the firearm is unloaded before installing or adjusting the trigger.
- Be aware of your surroundings and ensure that you are in a safe environment when handling firearms.
- Keep the trigger assembly and all firearm components out of reach of children and unauthorized users.
- Regularly inspect your trigger and firearm for any signs of wear or damage.
- Use only compatible firearms as specified in this guide.
- Follow all local laws and regulations regarding firearm use and modifications.

## Specific Safety Precautions for Use

### • Hazard Identification:

- Improper installation or adjustment may lead to accidental discharge.
- Adjusting the trigger pull weight too low can result in unintentional firing.
- Always use factory safety mechanisms as specified.

### • Avoiding Hazards:

- Ensure the firearm is pointed in a safe direction at all times.
- Do not attempt to adjust the trigger while the firearm is loaded.
- Make all adjustments in a controlled environment, free from distractions.
- If you experience any issues with the trigger, cease use immediately and consult a professional gunsmith.

### • Audience Specific Warnings:

- This product is intended for use by individuals aged 18 and over.
- Ensure that inexperienced users are supervised by a knowledgeable adult at all times.

## Instructions for Installation and Usage

### • Installation:

1. Ensure the firearm is completely unloaded and the safety is engaged.
2. Remove the existing trigger assembly from your Winchester Model 70 or Model 54, following the manufacturer's instructions.
3. Carefully install the WINCHESTER 70 TRIGGERS TIMNEY WINCHESTER 70 trigger in accordance with the included instructions.
4. Adjust the trigger weight of pull between 11/2 to 4 pounds as desired, ensuring the lock nuts are secured to hold settings.

5. Test the trigger function without ammunition to ensure it operates correctly.

- **Usage:**

1. Always perform a function check after installation and before use.
2. Adjust the overtravel as needed to ensure a clean trigger pull.
3. When ready to shoot, ensure the firearm is pointed in a safe direction.
4. Maintain proper shooting stance and grip while using the firearm.

- **Maintenance:**

- Regularly clean and inspect the trigger assembly and firearm to ensure optimal performance.
- Lubricate the trigger surfaces as recommended by the manufacturer.

## Disposal Instructions

- Dispose of the product in accordance with local regulations regarding firearm accessories.
- If the trigger is damaged beyond repair, contact local waste management services for proper disposal methods.
- Ensure that all components are disposed of in a manner that prevents unauthorized use.

## Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please refer to the manufacturer's contact information or consult a qualified gunsmith. Always prioritize safety and compliance with local laws when using firearm accessories.

Thank you for choosing the WINCHESTER 70 TRIGGERS TIMNEY WINCHESTER 70, BLUE TRIGGER. Enjoy safe and responsible shooting!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)