

RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA® PX4 FULL SIZE - RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA PX4 FULL SIZE

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

FITS: PX4, 9mm

RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA® PX4 FULL SIZE
Factory replacement recoil spring and guide rod assembly for Beretta® PX4
Full Size handgun.



Attributes

- Name: [RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA PX4 FULL SIZE](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913100744
- Mfr. No.: C83437
- Make: Beretta
- Model: PX4
- Delivery weight: 0.018kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA® PX4 FULL SIZE
- About Us

Safety Instruction Guide for RECOIL SPRING & GUIDE ROD ASSEMBLY FOR BERETTA® PX4 FULL SIZE

Introduction

Thank you for purchasing the Recoil Spring & Guide Rod Assembly for Beretta® PX4 Full Size. This guide provides essential safety instructions and usage information to ensure the safe and effective operation of your product. Please read this guide thoroughly before installation and use.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or installation.
- Keep the product out of reach of children and unauthorized persons.
- Use only compatible parts and accessories to avoid malfunction or injury.
- Regularly inspect the recoil spring and guide rod assembly for wear and damage.
- Follow all local laws and regulations regarding firearm maintenance and safety.

Specific Safety Precautions for Use

- Ensure the firearm is pointed in a safe direction during installation.
- Wear appropriate safety gear, such as eye protection, when handling the firearm or its components.
- Do not modify the recoil spring or guide rod assembly in any way.
- If you experience any malfunctions or unusual behavior during use, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools: screwdriver, cleaning cloth, and lubricant.

2. Installation:

- Remove the slide from the Beretta® PX4 Full Size.
- Locate the old recoil spring and guide rod assembly.
- Carefully remove the old assembly by pulling it out from its position.
- Take the new recoil spring and guide rod assembly and insert it into the slide.
- Ensure that the assembly is seated correctly and securely in place.

3. Reassembly:

- Reattach the slide to the frame of the firearm.
- Conduct a function check to ensure the slide operates smoothly.

4. Usage:

- Always follow firearm safety rules during shooting.
- Regularly clean and maintain the recoil spring and guide rod assembly to ensure optimal performance.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Contact local authorities or waste management services for proper disposal methods.

Contact Information for Further Support

- For any inquiries regarding safety or product performance, please consult your retailer or a qualified gunsmith.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on your responsible use of this product.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at