

EJECTOR, 680, RH - BERETTA USA EJECTOR, 680, RH

[Shotgun Parts](#) > [Receiver & Action Parts](#) > [Ejector Parts](#) > [Ejectors](#)

FITS: S682, 12

All ejectors require gunsmith fitting by Beretta qualified gunsmiths, they are not user installed.



Attributes

- Name: [BERETTA USA EJECTOR, 680, RH](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913300464
- Mfr. No.:
- Model: S682,680
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- Startpage
- EJECTOR 680 RH Safety Instruction Guide
- About Us

EJECTOR 680 RH Safety Instruction Guide

Introduction

Thank you for choosing the EJECTOR 680 RH by Beretta USA. This document provides essential safety instructions and guidelines to ensure the safe use and installation of your ejector. Please read this guide thoroughly before use.

General Safety Guidelines

- Ensure that all safety instructions are followed to prevent accidents and injuries.
- All ejectors require gunsmith fitting by Beretta qualified gunsmiths. They are not user installed.
- Always handle firearms with care and ensure they are unloaded when not in use.
- Store the ejector and all related components in a secure place, out of reach of children and unauthorized users.
- Regularly check for recalls or safety notices related to your product.

Specific Safety Precautions for Use

- Do not attempt to install or modify the ejector yourself. Only qualified Beretta gunsmiths should perform fitting.
- Ensure that the firearm is compatible with the EJECTOR 680 RH before installation.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Be aware of your surroundings and ensure you are in a safe environment when using your firearm.
- If you notice any irregularities or malfunctions, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation

- Only a qualified Beretta gunsmith should install the EJECTOR 680 RH.
- Provide the gunsmith with all necessary information about your firearm model (S682, 680).
- Ensure that the gunsmith uses appropriate tools and follows all safety protocols during installation.

2. Usage

- Always check that the ejector is functioning correctly before using the firearm.
- Follow all standard safety practices when handling and using your firearm.
- Do not use the firearm if the ejector does not operate as intended. Seek professional assistance.

Disposal Instructions

- Dispose of the ejector and any related components in accordance with local regulations.
- Ensure that all parts are rendered unusable before disposal to prevent unauthorized use.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any safety inquiries or concerns regarding your EJECTOR 680 RH, please reach out to your local Beretta dealer or qualified gunsmith.

Thank you for prioritizing safety while using your EJECTOR 680 RH. Your adherence to these guidelines helps ensure a safe and enjoyable experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk