

EJECTOR - BERETTA USA EJECTOR, RH

[Shotgun Parts](#) > [Receiver & Action Parts](#) > [Ejector Parts](#) > [Ejectors](#)

FITS: S682, .410

All ejectors require gunsmith fitting by Beretta qualified gunsmiths, they are not user installed.



Attributes

- Name: [BERETTA USA EJECTOR, RH](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913300669
- Mfr. No.: E45542
- Model: S682
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- [Startpage](#)
- [Ejector Beretta USA Ejector, RH Safety Instruction Guide](#)
- [About Us](#)

Ejector Beretta USA Ejector, RH Safety Instruction Guide

Introduction

Thank you for choosing the Ejector Beretta USA Ejector, RH. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of your ejector. Please read this manual carefully before use and installation to avoid potential hazards.

General Safety Guidelines

- Always ensure that the ejector is installed by a Beretta qualified gunsmith. Improper installation can lead to malfunctions or accidents.
- Keep the ejector and all firearms out of reach of children and unauthorized users.
- Regularly inspect your ejector and firearm for any signs of wear or damage. If any issues are found, consult a qualified gunsmith immediately.
- Follow all local laws and regulations regarding the ownership and use of firearms and their components.

Specific Safety Precautions for Use

- Do not attempt to install or modify the ejector yourself. Only a Beretta qualified gunsmith should perform these tasks.
- Always treat your firearm as if it is loaded, even when it is not. This includes ensuring that the ejector is functioning correctly before use.
- Avoid using the ejector with damaged or incompatible firearms, as this may lead to malfunctions or safety hazards.
- Ensure that you are in a safe environment when using your firearm equipped with the ejector, away from people and property that could be harmed.

Instructions for Installation and Usage

1. Installation:

- Take your firearm to a Beretta qualified gunsmith for the installation of the ejector.
- Ensure that the gunsmith follows all manufacturer specifications for the installation process.

2. Usage:

- After installation, familiarize yourself with the operation of your firearm and the ejector.
- Conduct a test to ensure that the ejector is functioning properly before engaging in any shooting activities.
- Always wear appropriate safety gear, including eye and ear protection, when using your firearm.

Disposal Instructions

- Dispose of any defective or damaged ejectors responsibly. Do not throw them in regular trash.
- Contact your local waste management authority for guidelines on the proper disposal of firearm components.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Ejector Beretta USA Ejector, RH, please consult a qualified

gunsmith or contact Beretta customer service. Ensure you have your product details available for reference.

Conclusion

Your safety is our priority. By following these guidelines and instructions, you can ensure the safe use and longevity of your Ejector Beretta USA Ejector, RH. Always prioritize safety and seek professional assistance when needed. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk