

TRG CARRY SLING DESERT TAN

Desert tan carry sling for Sako TRG.

NO IMAGE
AVAILABLE

Attributes

- Name: SAKO TRG CARRY SLING DESERT TAN
- Manufacturer: SAKO
- Product no.: 913500135
- Mfr. No.: 209529
- Color: Desert Tan
- Material: Nylon
- Delivery weight: 0.272kg
- Shipping height: 76mm
- Shipping width: 76mm
- Shipping length: 178mm

Table of Contents

- [Startpage](#)
- [English: SAKO TRG Carry Sling Safety Instruction Guide](#)
- [Polski: Instrukcja bezpieczeństwa dla torby transportowej SAKO TRG CARRY SLING DESERT TAN](#)

SAKO TRG Carry Sling Safety Instruction Guide

Introduction

Thank you for choosing the SAKO TRG Carry Sling in Desert Tan. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your product. Please read this guide carefully before using the sling.

General Safety Guidelines

- Ensure that the sling is used only for its intended purpose, which is to carry the Sako TRG firearm safely and securely.
- Always inspect the sling for any signs of wear or damage before each use. Do not use if damaged.
- Keep the sling out of reach of children and vulnerable individuals when not in use.
- Follow all local laws and regulations regarding firearm transportation and carrying.

Specific Safety Precautions for Use

- When attaching the sling to the firearm, ensure that it is securely fastened to prevent accidental detachment.
- Do not overload the sling beyond its designed capacity. The sling is intended for the Sako TRG and should not be used to carry additional weight.
- Avoid sharp objects or abrasive surfaces that could damage the nylon material of the sling.
- Always ensure that the firearm is unloaded before attaching or detaching the sling.
- Use caution when adjusting the sling length to avoid pinching or injury.

Instructions for Installation and Usage

1. Attaching the Sling:

- Locate the sling attachment points on your Sako TRG firearm.
- Align the sling clips with the attachment points.
- Press the clips firmly into place until you hear a click, indicating they are securely attached.

2. Adjusting the Sling Length:

- To adjust the length, locate the adjustment buckle on the sling.
- Pull the strap through the buckle to increase or decrease the length as needed.
- Ensure that the sling is adjusted to a comfortable length that allows for easy carrying.

3. Using the Sling:

- When carrying the firearm, ensure that the sling is positioned securely over your shoulder.
- Adjust the sling as necessary to maintain balance and comfort while walking or moving.

4. Removing the Sling:

- To detach the sling, press the release mechanism on the clips and carefully remove them from the attachment points.
- Store the sling in a cool, dry place when not in use to prolong its lifespan.

Disposal Instructions

- Dispose of the sling in accordance with local regulations for textile waste.
- If the sling is damaged beyond repair, consider recycling it if possible.
- Do not dispose of the sling in a manner that could pose a risk to the environment or public safety.

Contact Information for Further Support

For any questions or concerns regarding the SAKO TRG Carry Sling, please refer to the manufacturer's website or contact your local retailer for assistance. Always ensure that you have access to the latest safety information and guidelines.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your SAKO TRG Carry Sling!

Instrukcja bezpieczeństwa dla torby transportowej SAKO TRG CARRY SLING DESERT TAN

Wprowadzenie

Dziękujemy za zakup torby transportowej SAKO TRG CARRY SLING w kolorze pustynnym. Niniejsza instrukcja ma na celu zapewnienie bezpiecznego użytkowania produktu oraz dostarczenie niezbędnych informacji dotyczących jego obsługi. Prosimy o uważne zapoznanie się z poniższymi wytycznymi.

Ogólne wytyczne dotyczące bezpieczeństwa

- Upewnij się, że produkt jest używany zgodnie z jego przeznaczeniem.
- Regularnie sprawdzaj torbę pod kątem uszkodzeń, które mogą wpłynąć na jej bezpieczeństwo.
- Przechowuj torbę w suchym miejscu, z dala od źródeł ciepła i wilgoci.
- Nie stosuj torby do przenoszenia ciężkich lub ostrych przedmiotów, które mogą uszkodzić materiał.
- Zawsze zachowuj ostrożność podczas noszenia torby, aby uniknąć potknięć lub upadków.

Szczególne środki ostrożności podczas użytkowania

- Nie pozwól dzieciom bawić się torbą, aby uniknąć ryzyka uduszenia lub innych obrażeń.
- Używaj torby tylko w sposób zgodny z jej przeznaczeniem, tj. do transportu broni Sako TRG.
- Jeśli torba ulegnie uszkodzeniu, nie używaj jej i skontaktuj się z producentem w celu uzyskania dalszych informacji.
- Unikaj kontaktu torby z substancjami chemicznymi, które mogą uszkodzić materiał.

Instrukcje dotyczące instalacji i użytkowania

- **Montaż:**
 - Torba jest gotowa do użycia zaraz po wyjęciu z opakowania. Upewnij się, że wszystkie zamki i zapięcia działają prawidłowo.
- **Użytkowanie:**
 - Umieść broń Sako TRG w torbie, upewniając się, że jest odpowiednio zabezpieczona.
 - Zapięcie torby powinno być zawsze zamknięte podczas transportu.
 - Noś torbę na ramieniu lub w ręku, korzystając z wygodnych uchwytów.

Instrukcje dotyczące utylizacji

- Torbę transportową należy utylizować zgodnie z lokalnymi przepisami dotyczącymi odpadów.
- Nie wrzucaj torby do ognia ani nie spalaj jej, ponieważ może to spowodować wydzielanie szkodliwych substancji.
- Jeśli torba jest uszkodzona, rozważ jej recykling, jeżeli to możliwe, lub skontaktuj się z lokalnym punktem zbiórki odpadów.

Informacje kontaktowe w celu uzyskania dalszego wsparcia

W przypadku pytań dotyczących bezpieczeństwa lub użytkowania torby transportowej SAKO TRG CARRY SLING DESERT TAN, zalecamy kontakt z producentem lub autoryzowanym sprzedawcą. Wszelkie zapytania dotyczące bezpieczeństwa produktu można zgłaszać do odpowiednich organów.

Podsumowanie

Przestrzeganie powyższych wytycznych zapewni bezpieczne i efektywne użytkowanie torby transportowej SAKO TRG CARRY SLING DESERT TAN. Dziękujemy za uwagę i życzymy satysfakcji z użytkowania naszego produktu.