

TRG CARRY SLING DESERT TAN

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Slings](#)

Desert tan carry sling for Sako TRG.

NO IMAGE
AVAILABLE

Attributes

- Name: [SAKO TRG CARRY SLING DESERT TAN](#)
- Manufacturer: [SAKO](#)
- Product no.: 913500135
- Mfr. No.: 209529
- Colour: Desert Tan
- Material: Nylon
- Delivery weight: 0.272kg
- Shipping height: 76mm
- Shipping width: 76mm
- Shipping length: 178mm

Table of Contents

- [Startpage](#)
- [SAKO TRG Carry Sling Safety Instructions](#)
- [About Us](#)

SAKO TRG Carry Sling Safety Instructions

Introduction

Thank you for choosing the SAKO TRG Carry Sling in Desert Tan. This guide provides important safety information and instructions to ensure the safe use of your sling. Please read this manual carefully before using the product.

General Safety Guidelines

- Always inspect the sling before use to ensure it is in good condition and free from damage.
- Use the sling only for its intended purpose, which is to carry the Sako TRG firearm securely.
- Ensure that the sling is adjusted properly for your body size and the weight of the firearm.
- Keep the sling out of reach of children and vulnerable individuals when not in use.
- If you notice any signs of wear or damage, discontinue use immediately and replace the sling.

Specific Safety Precautions for Use

- Do not exceed the recommended weight limit of the sling.
- Avoid using the sling in wet or slippery conditions, as this may affect grip and control.
- Always ensure that the firearm is unloaded when attaching or detaching the sling.
- Use caution when adjusting the sling to avoid pinching or injury.
- Be aware of your surroundings when using the sling, particularly in crowded or confined spaces.

Instructions for Installation and Usage

Installation

1. **Identify Sling Attachment Points:** Locate the designated attachment points on your Sako TRG firearm.
2. **Attach the Sling:**
 - Slide the sling's clips or hooks onto the attachment points securely.
 - Ensure that the clips are fully engaged and cannot be accidentally detached.
3. **Adjust the Length:**
 - Pull the adjustment straps to achieve the desired length for comfort and stability.
 - Ensure that the sling allows for free movement without restricting your mobility.

Usage

1. **Carrying the Firearm:**
 - Place the sling over your shoulder or across your body to distribute the weight evenly.
 - Ensure that the firearm is secure and does not swing excessively.
2. **Adjusting the Sling:**
 - If necessary, adjust the length of the sling while maintaining a firm grip on the firearm.
 - Make sure the adjustment does not compromise the security of the firearm.
3. **Detaching the Sling:**
 - To remove the sling, carefully unclip it from the attachment points.
 - Store the sling in a safe place when not in use.

Disposal Instructions

- Dispose of the sling responsibly according to local regulations.
- If the sling is damaged beyond repair, consider recycling materials where possible.
- Do not dispose of the sling in regular household waste if it contains nonbiodegradable materials.

Contact Information for Further Support

For any questions or concerns regarding the safety and usage of the SAKO TRG Carry Sling, please refer to the manufacturer's website or customer service for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your SAKO TRG Carry Sling. Thank you for prioritizing safety and compliance with EU General Product Safety Regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk