

RUGER® MARK II™/MARK III™, & 22/45™ TARGET TRIGGER - VOLQUARTSEN RUGER® TARGET TRIGGER, SS

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Triggers](#)

Drop-In Trigger Job For .22 Pistols

Precision machined from billet for precise fit to cut down trigger weight and eliminate the heavy pressure required to move the factory part. Helps produce a more consistent pull for improved accuracy. Stop screw is adjustable for overtravel and pretravel with the gun fully assembled, so you get a no-creep pull. Ultra-smooth shoe offers more contact with the trigger finger. Available in Black anodized aluminum or polished stainless steel (SS). Includes trigger spring and trigger spring plunger.



Attributes

- Name: [VOLQUARTSEN RUGER® TARGET TRIGGER, SS](#)
- Manufacturer: [VOLQUARTSEN](#)
- Product no.: 930000123
- Mfr. No.: VC2TT-ST
- Finish: Stainless Steel
- Model: Mark I,Mark II,Mark III
- Style: Adjustable,Curved,Drop-In
- Weapon type: Ruger
- Delivery weight: 0.023kg
- Shipping height: 15mm
- Shipping width: 71mm
- Shipping length: 86mm
- UPC: 810162012441

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for RUGER® MARK II™ /MARK III™, & 22/45™ TARGET TRIGGER VOLQUARTSEN RUGER® TARGET TRIGGER, SS
- About Us

Safety Instruction Guide for RUGER® MARK II™/MARK III™, & 22/45™ TARGET TRIGGER VOLQUARTSEN RUGER® TARGET TRIGGER, SS

Introduction

Thank you for choosing the RUGER® MARK II™/MARK III™, & 22/45™ TARGET TRIGGER by VOLQUARTSEN. This guide provides essential safety information, installation instructions, and usage precautions to ensure your safe and effective use of this product. Please read this guide carefully before using the trigger.

General Safety Guidelines

- Ensure that all firearms are handled safely and responsibly.
- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Store firearms and ammunition separately and securely.
- Use appropriate personal protective equipment (PPE) such as eye and ear protection when using firearms.
- Do not modify the trigger or any other part of the firearm unless you are a qualified gunsmith.
- Regularly inspect your firearm and its components for wear and damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the firearm is completely unloaded before installation.
- Do not install or adjust the trigger while the firearm is loaded or in an unsafe condition.
- Use only compatible models: Ruger Mark I, Mark II, Mark III, and 22/45 pistols.
- Be aware that improper installation can lead to malfunction or accidental discharge.
- Adjust the stop screw only when the gun is fully assembled to avoid unintentional adjustments.
- Avoid using excessive force when pulling the trigger.
- Keep hands and fingers clear of the trigger area when installing or adjusting components.

Instructions for Installation and Usage

Installation

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools (e.g., screwdriver, pliers) for installation.

2. Remove the Factory Trigger

- Follow the manufacturer's instructions for disassembling your Ruger firearm.
- Carefully remove the factory trigger from the firearm.

3. Install the VOLQUARTSEN Target Trigger

- Align the new trigger with the trigger assembly.
- Insert the trigger into place, ensuring it fits snugly.
- Secure the trigger using the manufacturer's recommended fasteners.

4. Adjust the Stop Screw

- With the firearm fully assembled, adjust the stop screw for overtravel and pretravel to achieve a nocreep pull.
- Test the trigger pull to ensure it meets your preferences.

5. Reassemble the Firearm

- Follow the manufacturer's instructions to reassemble the firearm completely.
- Ensure all components are secured and functioning properly.

Usage

- Before firing, always conduct a function check to ensure the trigger operates correctly.
- Familiarize yourself with the new trigger pull and adjust your shooting technique as necessary.
- Always follow safe shooting practices and guidelines.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Contact local waste management authorities for information on safe disposal methods for firearm components.

Contact Information for Further Support

For any questions or concerns regarding the RUGER® MARK II™/MARK III™, & 22/45™ TARGET TRIGGER, please refer to your local authorized dealer or the manufacturer's website for support and additional resources.

By following these guidelines and instructions, you can ensure safe and effective use of your new trigger. Thank you for your attention to safety and responsible firearm handling.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk