

FOOLPROOF TARGET KNOBS - WILLIAMS GUN SIGHT TARGET ELEVATION GIB LOCK KNOB

[Gunsmith Tools](#) > [Sight & Scope Installation Tools](#) > [Replacement Sight Screws](#)

All Foolproof sights (except TK models) use the Short Elevation Knob. The Long Elevation Knob is for use with Foolproof-TK target sights. The Elevation Gib Lock Knob fits both standard Foolproof and Foolproof-TK models



Attributes

- Name: [WILLIAMS GUN SIGHT TARGET ELEVATION GIB LOCK KNOB](#)
- Manufacturer: [WILLIAMS GUN SIGHT](#)
- Product no.: 962000079
- Mfr. No.: 61613
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 005350616130

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [FOOLPROOF TARGET KNOBS SAFETY INSTRUCTIONS](#)
- [About Us](#)

FOOLPROOF TARGET KNOBS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the FOOLPROOF TARGET KNOBS by WILLIAMS GUN SIGHT. These knobs are designed to enhance your shooting experience by providing precise elevation adjustments. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or adjusting any components.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product for any visible damage or defects before use. Do not use if damaged.
- Be aware of your surroundings when using firearms and ensure you are in a safe shooting environment.
- Follow all local laws and regulations regarding the use of firearms and related accessories.

Specific Safety Precautions for Use

- Ensure the FOOLPROOF TARGET KNOB is compatible with your sight model before installation.
- When adjusting the elevation knob, do so gently to avoid damaging the mechanism.
- If you experience any resistance while adjusting the knob, stop immediately and check for obstructions or misalignment.
- Avoid using excessive force when fitting the knob, as this may cause damage to both the knob and the sight.
- Periodically check the tightness of the knob to ensure it remains securely attached during use.

Instructions for Installation and Usage

Installation

1. **Compatibility Check:** Confirm that you have the correct elevation knob for your sight model (Short Elevation Knob for standard models, Long Elevation Knob for FoolproofTK models).
2. **Preparation:** Ensure your firearm is unloaded and in a safe position.
3. **Remove Old Knob:** If replacing an existing knob, carefully unscrew it from the sight.
4. **Fit the New Knob:** Align the new FOOLPROOF TARGET KNOB with the threads of the sight. If necessary, grind the tip of the threads to ensure a proper fit.
5. **Secure the Knob:** Gently screw the knob into place. Do not overtighten to avoid damaging the sight.

Usage

1. **Adjusting Elevation:** Turn the knob clockwise to raise the sight and counterclockwise to lower it. Make adjustments gradually and check your alignment after each adjustment.
2. **Regular Checks:** Periodically inspect the knob during use to ensure it is functioning correctly and securely attached.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic and metal waste.
- Do not dispose of the product in regular household waste.
- Consider recycling the aluminum and steel components if facilities are available in your area.

Contact Information for Further Support

For any questions or concerns regarding the FOOLPROOF TARGET KNOBS, please refer to the manufacturer's contact details provided with your product packaging or visit the manufacturer's website for additional resources and support.

By following these safety instructions, you can ensure a safe and enjoyable experience with your FOOLPROOF TARGET KNOBS. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk